

FRONT

PICTURE 1

November 1991

This supplement contains instructions for using the IBM Personal System/2 Service Aid Diskette.

The systems supported are listed on the diskette.

Insert this supplement in the IBM Personal System/2 *Hardware Maintenance Service* manual (part number 15F2220, form number SBOF-3988-00).

Part Number 10G6618

Form Number S10G-6311-01

FRONT_1 Safety Information

Refer to the *Hardware Maintenance Service General Information* pamphlet for the following information:

- General Safety
- Electrical Safety
- Safety Inspection Guide.

First Edition (November 1991)

The following paragraph does not apply to the United Kingdom or any country where such provisions are inconsistent with local law:

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time.

It is possible that this publication may contain reference to, or information about, IBM products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that IBM intends to announce such IBM products, programming, or services in your country.

Requests for technical information about IBM products should be made to your IBM Authorized Dealer or your IBM Marketing Representative.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to the IBM Director of Commercial Relations, IBM Corporation, Purchase, NY 10577.

| Copyright International Business Machines Corporation 1991. All rights reserved.

Note to U.S. Government users-Documentation related to Restricted rights-Use, duplication, or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

FRONT_2 Notices

References in this publication to IBM products, programs, or services do not imply that IBM intends to make these available in all countries in which IBM operates. Any reference to an IBM product, program or service is not intended to state or imply that only IBM's product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any of IBM's intellectual property rights or other legally protectable rights may be used instead of the IBM product, program, or service. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by IBM, are the user's responsibility.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to the IBM Director of Commercial Relations, IBM Corporation, Purchase, NY 10577.

The following terms, denoted by an asterisk (*) in this publication, are trademarks of the IBM Corporation in the United States and/or other countries:

IBM
OS/2
Personal System/2.
PS/2

1.0 Service Aid Diskette Version 2.0

The IBM (*) PS/2 (*) Service Aid Diskette Version 2.0 is screen driven and provides TRAP 0002 and nonmaskable interrupt error information. This information will help you resolve TRAP 0002 and nonmaskable interrupt errors on supported PS/2 systems. This pamphlet contains the procedures to support the diskette.

Systems Supported

- 8535
- 8540
- 8543 L40SX
- 8555
- 8565
- 8570
- 8573 P70 and 8573 P75
- 8580.

Note: The **View the NMI error log** utility program does not support the 8535, 8540, 8543 L40SX, and 8555 SX systems.

Main Menu

The main menu on this diskette contains a list of utilities and a nonmaskable interrupt (NMI) Error Log Menu. These utilities and the NMI Error Log Menu are designed to:

- Read the nonmaskable interrupt error log (see "View the NMI error log" in topic 6.1)
- Install and remove a TRAP 0002 device driver (see "Install the TRAP 0002 device driver for OS/2 V1.3" in topic 6.2 and "Remove the TRAP 0002 device driver for OS/2 V1.3." in topic 6.3)

Note: Obtain the customers consent prior to installing the Trap 0002 device driver.

- Identify the type of memory installed on the system board (see "View the type of memory installed on the system board" in topic 6.4)
- Convert hex addresses associated with system-board parity errors to system board memory-connector locations (see "Convert hex addresses associated with system board parity errors to memory connectors" in topic 6.5).

(*) Trademark of the IBM Corporation.

2.0 Starting the Diskette

1. Power-off the system.
2. Insert the service aid diskette in drive A.
3. Power-on the system and follow the instructions on the screen.

3.0 Installing the TRAP 0002 Device Driver

Use this procedure to install the device driver with OS/2 (*) Version 1.3 and customer service diskette (CSD) level WR05000 or higher installed as the primary operating system. For additional information about the device driver, see "Install the TRAP 0002 device driver for OS/2 V1.3" in topic 6.2.

1. Start the system with OS/2 Version 1.3.
2. After OS/2 is loaded, insert the service aid diskette in drive A.
3. Open an OS/2 window (see "Opening an OS/2 Window" in topic 5.0).
4. At the command prompt (1) type

```
copy config.sys + a:\line.txt
```

then press **Enter**. This will cause a carriage return at the end of the last line of text in the config.sys file.

5. Type

```
ddinstal
```

then press **Enter** and follow the instructions on the screen.

The TRAP 0002 device driver installation procedure has been completed.

(*) Trademark of the IBM Corporation.

(1) A displayed symbol, such as C:\, where a user enters commands.

4.0 Removing the TRAP 0002 Device Driver

Use this procedure to remove the device driver from the system and the statement added to the CONFIG.SYS file during the device driver installation procedure. For additional information about removing the device driver, see "Remove the TRAP 0002 device driver for OS/2 V1.3." in topic 6.3.

1. Start the system with OS/2 Version 1.3.
2. After OS/2 is loaded, insert the service aid diskette in drive A.
3. Open an OS/2 window (see "Opening an OS/2 Window" in topic 5.0).
4. At the command prompt type

a:

then press **Enter**.

5. Type

nmiremov

then press **Enter** and follow the instructions on the screen.

The device driver removal procedure has been completed. To implement the changes, press **Ctrl+Alt+Del** to restart the system.

5.0 Opening an OS/2 Window

From an OS/2 window, you can type information at the command prompt. Use this procedure to open a window.

1. After OS/2 is loaded in the system, press **Ctrl+Esc** to display the Task List.
2. Use the arrow keys to highlight **Group - Main**, then press **Enter**.
3. Use the arrow keys to highlight **OS/2 Window**, then press **Enter**.

An OS/2 window is now ready for you to enter OS/2 commands.

6.0 Utilities

From the main menu you can select the NMI Error Log menu or other utility programs. To do this, enter the appropriate number (located in the left column on the menu) you want to select and press enter, or use the keyboard arrow keys to highlight the appropriate menu or other utility program and then press enter. The Utility selections, followed by their descriptions, are listed below.

Subtopics

- 6.1 View the NMI error log
- 6.2 Install the TRAP 0002 device driver for OS/2 V1.3
- 6.3 Remove the TRAP 0002 device driver for OS/2 V1.3.
- 6.4 View the type of memory installed on the system board
- 6.5 Convert hex addresses associated with system board parity errors to memory connectors

6.1 View the NMI error log

This utility displays the **Error Log menu**. From the **Error Log menu** you can view the Trap 0002 information stored in the NMI error log. This utility is compatible with OS/2 Version 1.2 or higher installed as the primary operating system. The other utilities on the Error Log menu provide more information about the particular errors that are stored in the error log. These utilities are compatible on systems with nonvolatile memory (NVRAM) only, and are not compatible with the 8535, 8540, 8543 L40SX and 8555 SX systems. If errors are stored in the NMI error log, and OS/2 Version 1.3 is installed as the primary system, the TRAP 0002 device driver can be installed on the system (with the consent of the customer).

6.2 Install the TRAP 0002 device driver for OS/2 V1.3

This utility provides the procedure for installing the TRAP 0002 device.

Notes:

1. Obtain the customers consent prior to installing the Trap 0002 device driver.
2. The device driver will occupy approximately 5KB (KB equals 1024) of space on the hard disk.

The TRAP 0002 device driver works only on systems with OS/2 Version 1.3 and corrective service diskette (CSD) level WR05000 or higher installed. The install procedure loads the device driver on the hard disk and automatically writes a statement in the CONFIG.SYS file to activate the device driver when OS/2 is started. It provides additional support in reporting TRAP 0002 errors. If a system-board parity error is detected, the device driver displays, on the screen, the connector location of the failing system board memory. The service aid diskette can then be used to view the type of memory installed on the system board. When no longer needed, the Trap 0002 device driver may be removed from the system.

Note: When the device driver is installed on the system, the TRAP error is displayed on the screen and is not stored in NVRAM.

6.3 Remove the TRAP 0002 device driver for OS/2 V1.3.

This utility provides the procedure for removing the TRAP 0002 device driver. It removes the device driver from the hard disk and the device driver statement from the CONFIG.SYS file.

6.4 View the type of memory installed on the system board

This utility identifies the type and location of the memory installed on the system board. It is compatible with all systems supported by this service aid diskette, regardless of the type of operating system installed.

Convert hex addresses associated with system board parity errors to memory connectors

6.5 Convert hex addresses associated with system board parity errors to memory connectors

This utility changes hex addresses (associated with system board parity errors) to memory-connector locations. This utility is compatible with DOS and other operating systems that display the failing address on the screen when a system board parity error occurs.

7.0 OS/2 and the High Performance File System

If a TRAP 0002 error occurs on a system running OS/2 with the high performance file system (HPFS) installed, the system will halt and display a TRAP 0002 screen. When restarted, the system might display a TRAP D error on the screen and halt all system operations. If this occurs, do the following to recover the hard disk drive:

1. Insert the OS/2 Version 1.3 Installation Diskette in drive A.
2. Press **Ctrl+Alt+Del**.
3. At the logo screen, press **Esc** to display the OS/2 command prompt.
4. Replace the installation diskette with the OS/2 Version 1.3 Diskette 1.

Note: If OS/2 is installed on a drive other than **C**, replace the letter **c** in the next step with the letter of the drive that contains OS/2.

5. At the command prompt type

```
chkdsk c: /f
```

then press **Enter**.

6. When the check disk program has been completed, remove diskette 1 from drive A.
7. Press **Ctrl+Alt+Del** to restart the system.

To prevent the TRAP D error from appearing each time the customer starts the system, tell the customer to use the shutdown utility on the Desktop Manager menu before they power-off the system. To do this:

1. Press **Ctrl+Esc** to display the Task List.
2. Use the arrow keys to highlight **Desktop Manager**, then press **Enter**.
3. Press **Alt+D** to select the Desktop action bar.
4. Use the arrow keys to select **Shutdown**, then press **Enter**.
5. Follow the instruction on the screen until the system is shut down.

Printed in the United States of America