

*TITLE Title Page*

**IBM 4684 Store Loop Adapter/A:**

**Installation,  
Testing,  
Problem Determination,  
and Technical Reference**

Document Number SD21-0045-00

COVER Book Cover

---

**IBM 4684 Store Loop Adapter/A:**

**Installation,  
Testing,  
Problem Determination,  
and Technical Reference**

Document Number SD21-0045-00

Part Number 92F5869

---

*EDITION Edition Notice*  
**First Edition (April 1991)**

This is the first edition of the *IBM\* 4684 Store Loop Adapter/A: Installation, Testing, Problem Determination, and Technical Reference*.

Changes are made periodically to the information herein. Before using this publication in connection with the operation of IBM systems, consult the latest *IBM System/370 Bibliography of Industry Systems and Application Programs*, GC20-0370, for the editions that are applicable and current.

References in this publication to IBM products, programs, or services do not imply that IBM intends to make these available in all countries in which IBM operates. Any reference to an IBM product, program, or service in this publication is not intended to state or imply that only IBM's product, program, or service may be used. Any functionally equivalent product, program, or service may be used. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by IBM, are the user's responsibility.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to the IBM Director of Commercial Relations, IBM Corporation, Purchase, NY 10577.

Publications are not stocked at the address given below. Requests for IBM publications should be made to your IBM representative or to the IBM branch office serving your locality.

A form for readers' comments is provided at the back of this publication. If the form has been removed, comments may be addressed to IBM Corporation, Information Development, Department E35, P.O. Box 12195, Research Triangle Park, North Carolina, USA 27709. IBM may use or distribute whatever information you supply in any way it believes appropriate without incurring any obligation to you.

**Special Notices**

The following terms used in this publication, denoted by an asterisk (\*), are trademarks of the IBM Corporation in the United States and/or other countries:

IBM	Micro Channel	Personal System/2
PS/2		

**| Copyright International Business Machines Corporation 1991. All rights reserved.**

Note to U.S. Government Users -- Documentation related to restricted rights -- Use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

NOTICES Notices

**Federal Communications Commission (FCC) Statement**

**Note:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

*FRONT\_1 Telecommunications Safety Requirements -- United Kingdom*

This IBM product is made to high safety standards. It complies inherently with telecommunications safety standard BS 6301. It is not designed to provide protection from excessive voltages introduced externally at its DTE interface. Therefore, when this product is connected to a public telecommunications network and you connect to this product items not supplied by IBM United Kingdom Limited, you must ensure that you comply with mandatory telecommunications safety requirements.

You may do this either by choosing products which also are approved as complying to BS 6301 or British Telecom Technical Guide 26, or by the use of approved safety barriers. Please consult the local office of your public telecommunications operator for advice and permission to make the connections.

*FRONT\_2 Canadian Department of Communications Compliance Statement*

This equipment does not exceed Class A limits per radio noise emissions for digital apparatus, set out in the Radio Interference Regulation of the Canadian Department of Communications. Operation in a residential area may cause unacceptable interference to radio and TV reception requiring the owner or operator to take whatever steps are necessary to correct the interference.

**Avis de conformité aux normes du ministère des Communications du Canada**

Cet équipement ne dépasse pas les limites de Classe A d'émission de bruits radioélectriques pour les appareils numériques, telles que prescrites par le Règlement sur le brouillage radioélectrique établi par le ministère des Communications du Canada. L'exploitation faite en milieu résidentiel peut entraîner le brouillage des réceptions radio et télé, ce qui obligerait le propriétaire ou l'opérateur à prendre les dispositions nécessaires pour en éliminer les causes.

FRONT\_3 General Safety Considerations (U.S. English)

DANGER

+-----+  
| Never connect or disconnect a cable during an electrical storm. |  
+-----+

CAUTION:

For your safety, you must connect the power cable of any equipment to a correctly wired and grounded receptacle. An incorrectly wired receptacle can place a hazardous voltage on accessible metal parts of the equipment. If you are unsure of the receptacle wiring, have a qualified electrician check the receptacle prior to connecting any equipment or working on any equipment connected to it.

This product is equipped with a 3-wire power cord and plug for the user's safety. Use this power cord in conjunction with a properly grounded electrical outlet to avoid electrical shock.

CONTENTS Table of Contents

TITLE	Title Page
COVER	Book Cover
EDITION	Edition Notice
NOTICES	Notices
FRONT_3	General Safety Considerations (U.S. English)
CONTENTS	Table of Contents
1.0	Chapter 1. Introduction
1.1	Related Publications
2.0	Chapter 2. Installation Instructions
2.1	Installation Steps
3.0	Chapter 3. Configuring and Testing the Store Loop Adapter
3.1	Configuration and Verification Tests
4.0	Chapter 4. Problem Determination Procedures
4.1	Running Tests
4.2	Failures During the Power-On Self-Test (POST)
4.2.1	Store Loop Adapter Failure
4.3	Failures During Diskette Testing
4.3.1	Store Loop Diagnostic Errors
5.0	Chapter 5. Technical Reference
5.1	Store Loop Adapter Cable Diagram
5.2	Adapter Loop Relay Diagram
5.3	Store Loop Adapter Block Diagram
5.4	Store Loop Adapter Storage Map
5.5	POST Test Store Loop Adapter Errors
5.6	Adapter Failure Status Bytes
5.7	Failure Status Byte 0
5.7.1	Store Loop Adapter Error Code
5.8	Failure Status Byte 1
5.8.1	Store Loop Adapter Microprocessor Status Codes
5.9	Failure Status Bytes 2 and 3
5.9.1	Shared Buffer Latch Error Codes and Extended Data
5.10	Failure Status Bytes 4 and 5
5.10.1	Shared Buffer Error Codes and Test Patterns
5.11	Store Loop Adapter System Status Byte
5.12	Shared Buffer Request Byte
5.13	Shared Buffer Status Byte
5.14	Store Loop Adapter Interrupt Flag Byte
A.0	Appendix A. Parts Catalog
B.0	Appendix B. Warranty Information
B.2	STATEMENT OF LIMITED WARRANTY
INDEX	Index

1.0 Chapter 1. Introduction

This manual contains installation and testing instructions for installing or replacing an IBM 4684 Store Loop Adapter/A in supported models of an IBM 4684 Point of Sale Terminal used as a store controller to run a store loop. This manual also includes problem determination procedures and technical reference information.

Use this manual with the *4684 Reference Diskette* for your IBM 4684 Point of Sale Terminal. The reference diskette must be a version 3.0 or higher in order to support an IBM 4684 Store Loop Adapter/A.

Save this manual for future use after installing an IBM 4684 Store Loop Adapter/A.

Subtopics

1.1 Related Publications

1.1 Related Publications

The following publications contain additional information that may assist you with the store loop:

- IBM 4680 Store System: Messages Guide - SC30-3521
- IBM 4680 Store System: Problem Determination Guide - SY27-0316
- IBM 4683/4684 Point of Sale Terminal: Maintenance Manual - SY27-0295
- IBM 4684 Point of Sale Terminal: Problem Determination Guide - SY27-0314
- IBM 4684 Point of Sale Terminal: Installation Guide - SA27-3837.

2.0 Chapter 2. Installation Instructions

The IBM 4684 Store Loop Adapter/A is installed similar to other option adapters and PS/2 option adapters that are supported in an IBM 4684 Point of Sale Terminal. Use the steps that follow to assist you with installation of the adapter.

**Note:** Before you begin to install this adapter, be sure that you have a backup copy of the *IBM 4684 Point of Sale Terminal: Reference Diskette*, version 3.0 or higher. Refer to the *IBM 4684 Point of Sale Terminal: Installation Guide* or to the *IBM 4684 Point of Sale Terminal: Problem Determination Guide* for instructions on creating the backup copy of the reference diskette.

Subtopics

2.1 Installation Steps

## 2.1 Installation Steps

1. Switch **POWER OFF** on the IBM 4684 Point of Sale Terminal and disconnect the power cord from the electrical outlet, if not previously done.

Switch **POWER OFF** and disconnect any power cords from the electrical outlets of any attached devices that have their own power cord.

PICTURE 1

2. Check the cover lock at the front of the system unit and be sure that the lock is in the unlocked position. Lift straight up on the back panel at the rear of the system unit and remove the rear panel.

Disconnect all cables at the rear of the system unit. You should note the socket location for each cable you remove to allow correct cable replacement later.

Warning: Do not open the anti-static bag on any adapter until instructed to do so. Some adapters can be damaged by static discharge. To prevent this damage, the adapters are wrapped in anti-static bags.

3. Turn the thumbscrew [1] to loosen the system unit cover. Remove the system unit cover by sliding it forward approximately 2.5 cm (1 in.) and lifting it.

Continue to step 4.

PICTURE 2

4. Do you have a Feature Card Expansion [1] from Box 1C to install?  
- OR -  
Do you have a Feature Card and Memory Expansion Adapter [2] from Box 1D to install?

**Note:** Either the Feature Card Expansion or the Feature Card and Memory Expansion Adapter must be present to allow for installation of the IBM 4684 Store Loop Adapter/A option.

**NO (already installed)** Continue to step 6.

**YES** Continue to step 5.

5. Install the Feature Card Expansion from Box 1C or the Feature Card and Memory Expansion Adapter from Box 1D as shown in the diagram. Be sure the card is firmly seated in place.

**Note:** If you have an expandable memory card, you may need to install memory modules onto the card before you install the card into the machine. Adapters vary in their instructions.

[1] Feature Card Expansion

[2] Feature Card and Memory Expansion Adapter

PICTURE 3

PICTURE 4

6. Unpack the IBM 4684 Store Loop Adapter/A from the box.

Hold the adapter (still wrapped in its anti-static bag) in one hand. With your other hand, touch an unpainted metal part on the rear of the terminal. This will discharge any static buildup.

Carefully slide the anti-static bag back from the end of the adapter and remove the anti-static bag. Handle the adapter only by the edges; do not touch the connectors, components, or solder connections.

4684 Store Loop Adapter/A  
Installation Steps

There are two slots (1 or 2) in the system unit that can be used for option adapters. You may use either slot 1 or slot 2 for the store loop adapter.

7. Loosen the thumbscrews [1] that hold the small blank cover strip at the position where you will install the store loop adapter.

Remove and discard the cover strip.

8. The store loop adapter has blue tabs on two corners.

Install the store loop adapter by holding the blue tabs as shown in the diagram.

9. Hold and maneuver the adapter behind the slot entrance. Check to see that each adapter is firmly seated in its socket.

Tighten the thumbscrew (where the blank cover strip was removed earlier) to secure the adapter in position.

10. Replace the system unit cover by placing it approximately 2.5 cm (1 in.) from the rear and sliding it on.

Turn the thumbscrew [1] to secure the cover.

Continue to step 11.

PICTURE 5

PICTURE 6

PICTURE 7

PICTURE 8

11. When you have finished installing all devices, options, and cables:

- a. Connect all previously disconnected cables to the system unit.
- b. Connect the store loop adapter cables to the proper store loop adapters.

**Note:** To run the adapter tests, you must have the store loop adapter CABLE connected to the adapter, BUT disconnected from the store loop receptacle.

**CAUTION:**

This product is equipped with a 3-wire power cord and plug for the user's safety. Use this power cord in conjunction with a properly grounded electrical outlet to avoid electrical shock.

- c. Connect all external device power cords to their power outlets.
- d. Connect the power cable to the 4684 terminal and plug the power

cable into an electrical outlet.

**This completes the installation of the IBM 4684 Store Loop Adapter/A.**

Continue with Chapter 3 to ensure that the adapter is configured and operating correctly.

3.0 Chapter 3. Configuring and Testing the Store Loop Adapter

Before you begin to configure or test this adapter, be sure that you have a backup copy of the *IBM 4684 Point of Sale Terminal: Reference Diskette*, Version 3.0 or higher.

To run the adapter tests, you must have the store loop adapter CABLE connected to the adapter, BUT disconnected from the store loop receptacle.

DANGER

```
+-----+
| Never connect or disconnect a cable during an electrical storm. |
+-----+
```

Subtopics

3.1 Configuration and Verification Tests

3.1 Configuration and Verification Tests

1. Insert the backup copy of the 4684 Reference Diskette, Version 3.0 or higher, in the 4684 diskette drive and switch power ON. Follow the instructions that appear on the screen.

If the 4684 terminal stops with message "165" displayed, press the **S1** or the **ESC** key. Then, follow the instructions on the display.

2. When message "**M0101**" is displayed, answer **YES**. Automatic configuration will begin.
3. When the question "**Do you want to activate the new configuration now?**" is displayed, answer **YES**, and follow the instructions on the screen.

PICTURE 9

4. When **Menu-M1** is displayed, select "**Start Tests**".
5. When **Menu-T1** is displayed, select "**Verification Tests**".
  - The verification tests check the memory, the display, the IBM 4684 Store Loop Adapter/A, and other components of the system.
  - If an error occurs, make note of any components that fail the tests, and record any messages.
6. When testing is complete, be sure to connect the store loop cables to the proper store loop receptacles.

*4.0 Chapter 4. Problem Determination Procedures*

This chapter lists error symptoms and failing components related to the store loop adapter. The error symptoms can occur during power-on self-test or while running tests. When using the chapter, note that:

- x in an error message can be any number.
- The index lists the component that is most likely to be failing first.

## Subtopics

## 4.1 Running Tests

## 4.2 Failures During the Power-On Self-Test (POST)

## 4.3 Failures During Diskette Testing

#### 4.1 Running Tests

Before you begin to test a terminal, be sure that you have a backup copy of the *IBM 4684 Point of Sale Terminal: Reference Diskette*, Version 3.0 or higher.

DANGER

```
+-----+  
| Never connect or disconnect a cable during an electrical storm. |  
+-----+
```

**Note:** If your terminal is connected to a store loop, through a store loop adapter, you must have the store loop adapter CABLE connected to the adapter, BUT disconnected from the store loop receptacle.

To run tests on your 4684 terminal, see "Running Tests" in Chapter 1 of the *IBM 4684 Point of Sale Terminal: Problem Determination Guide*.

**Always replace an IBM 4684 Store Loop Adapter/A in the same system unit slot from which a store loop adapter was removed.**

4.2 Failures During the Power-On Self-Test (POST)

Run diagnostics from the backup copy of the *IBM 4684 Point of Sale Terminal: Reference Diskette* (Version 3.0 or higher) to isolate the failure.

Symptom	Failing Component
C0000	System unit or an option card
C4000	System unit or an option card
C8000	System unit or an option card
CC000	System unit or an option card
D0000	System unit or an option card
D4000	System unit or an option card

Subtopics

4.2.1 Store Loop Adapter Failure

4.2.1 Store Loop Adapter Failure

Run the IBM 4684 Store Loop Adapter/A test and follow the instructions on the screen to isolate the failure. xx in an error message can be any number.

Symptom	Failing Component
62xx	Store loop adapter

*4.3 Failures During Diskette Testing*

Run diagnostics from the backup copy of the *IBM 4684 Point of Sale Terminal: Reference Diskette* (Version 3.0 or higher) to isolate the failure.

Subtopics

4.3.1 Store Loop Diagnostic Errors

4.3.1 Store Loop Diagnostic Errors

Symptom	Failing Component
6210	Store loop adapter
6270	Store loop adapter cable or store loop adapter

5.0 Chapter 5. Technical Reference

Subtopics

- 5.1 Store Loop Adapter Cable Diagram
- 5.2 Adapter Loop Relay Diagram
- 5.3 Store Loop Adapter Block Diagram
- 5.4 Store Loop Adapter Storage Map
- 5.5 POST Test Store Loop Adapter Errors
- 5.6 Adapter Failure Status Bytes
- 5.7 Failure Status Byte 0
- 5.8 Failure Status Byte 1
- 5.9 Failure Status Bytes 2 and 3
- 5.10 Failure Status Bytes 4 and 5
- 5.11 Store Loop Adapter System Status Byte
- 5.12 Shared Buffer Request Byte
- 5.13 Shared Buffer Status Byte
- 5.14 Store Loop Adapter Interrupt Flag Byte

5.1 Store Loop Adapter Cable Diagram

This figure shows a store loop adapter cable and a diagram of the cable wiring.

PICTURE 10

5.2 Adapter Loop Relay Diagram

This figure is a diagram of the loop relay circuitry located in a store loop adapter.

PICTURE 11

5.3 Store Loop Adapter Block Diagram

This figure is a block diagram of an IBM 4684 Store Loop Adapter/A.

PICTURE 12

5.4 Store Loop Adapter Storage Map

These tables illustrate the store loop adapter storage areas. The values for memory addresses are in hexadecimal. You can find the actual address values for your adapter by finding the "base address" of your adapter and then adding the "base address plus" value.

Base Address	Adapter Default
C0000	First
C4000	Second
C8000	Third
CC000	Fourth
D0000	Fifth
D4000	Sixth

Base Address Plus	Start Memory Usage
0000	ROS
2800	Shared Buffer
2FFF	System Status Byte
3FF0	Failure Status Bytes
3FFF	End

5.5 POST Test Store Loop Adapter Errors

Table 5-1. POST Test Store Loop Errors	
Symptom	Cause
6211 - 6218	Multiple errors
6221 - 6228	8051 POR errors
6231 - 6238	Latch test errors
6241 - 6248	Shared buffer errors

5.6 Adapter Failure Status Bytes

The store loop adapter failure status bytes appear on the screen when the diagnostics detect a failure in a store loop adapter.

XX represents a FAILURE STATUS BYTE. It may be any number depending on the type of store loop adapter failure that occurred.

PICTURE 13

The tables on the following pages define the meaning of the store loop adapter failure status bytes. These bytes are displayed only when a failure is detected by the store loop adapter tests.

**Use this table to find information on the store loop adapter failure status bytes.**

For	Go to
Byte 0	"Store Loop Adapter Error Code" in topic 5.7.1.
Byte 1	"Store Loop Adapter Microprocessor Status Codes" in topic 5.8.1.
Byte 2 and Byte 3	"Shared Buffer Latch Error Codes and Extended Data" in topic 5.9.1.
Byte 4 and Byte 5	"Shared Buffer Error Codes and Test Patterns" in topic 5.10.1.
Byte 6	Not used
Byte 7	Not used
Byte 8	Contains the EC level of the store loop adapter microprocessor.
Byte 9	Contains the EC level of the store loop adapter power-on self test microcode in ROS.

5.7 Failure Status Byte 0

Subtopics

5.7.1 Store Loop Adapter Error Code

5.7.1 Store Loop Adapter Error Code

This table defines the meaning of each bit of failure status byte 0 of the store loop adapter failure status bytes.

Bit	Error	Values
7	Cable wrap	0 = Good 1 = Bad
6	Reserved	0 = Good 1 = Bad
5	ROS scan error	0 = Good 1 = Bad
4	Store loop adapter microprocessor status	0 = Good 1 = Bad
3	Shared buffer latch error code	0 = Good 1 = Bad
2	Shared buffer error code	0 = Good 1 = Bad
1	Reserved	0 = Good 1 = Bad
0	Reserved	0 = Good 1 = Bad

5.8 Failure Status Byte 1

Subtopics

5.8.1 Store Loop Adapter Microprocessor Status Codes

## 5.8.1 Store Loop Adapter Microprocessor Status Codes

This table defines the meaning of failure status byte 1 of the store loop adapter failure status bytes.

Table 5-2. Store Loop Adapter Microprocessor Status Codes	
Byte 1 Status Code	Definition
00	No errors occurred
30	The store loop adapter microprocessor internal diagnostic test failed.
33 thru 56	The store loop adapter microprocessor internal diagnostic test failed.
60	Microprocessor instruction time-out has occurred.
61	A serializer overrun occurred.
62	A tag overrun occurred.
63	A deserializer overrun occurred.
65	A loop shut-off command occurred.
66	The "Beacon Timer" has expired in secondary mode.
67	The "End-Of-Poll Timer" has expired in primary mode.
68	A CRC error occurred in a message received from the system unit microprocessor.
69	A store loop adapter microprocessor internal buffer overflow occurred.
6A	A store loop adapter microprocessor external buffer overflow occurred.
71 to 77	The store loop adapter microprocessor internal diagnostic test failed.
85	The store loop adapter microprocessor internal diagnostic test failed.

5.9 Failure Status Bytes 2 and 3

Subtopics

5.9.1 Shared Buffer Latch Error Codes and Extended Data

## 5.9.1 Shared Buffer Latch Error Codes and Extended Data

This table defines the meaning of failure status bytes 2 and 3 of the store loop adapter failure status bytes.

Table 5-3. Shared Buffer Latch Error Codes and Extended Data		
Byte 2 Error Code	Byte 3 Extended Data	Definition
00	00	No errors detected
01	Store loop adapter system status byte. See page 5.11.	The store loop adapter microprocessor was not at a "ready and not enabled" condition after initial POR was complete.
02	Store loop adapter interrupt flag byte. See page 5.14.	A level 7 software interrupt was not received when expected.
03	Store loop adapter system status byte. See page 5.11.	A level 7 hardware interrupt was not received when expected.
04	Shared buffer request byte. See page 5.12.	The 4684 microprocessor was unable to find the shared buffer after initial POR was complete.
05	Store loop adapter system status byte. See page 5.11.	The store loop adapter microprocessor was not at a "ready and not enabled" condition after initial POR was complete.
06	Shared buffer request byte. See page 5.12.	The 4684 microprocessor was unable to return the shared buffer to the store loop adapter microprocessor after initial POR was complete.
07	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer for a software POR request.
08	Shared buffer request byte. See page 5.12.	The 4684 microprocessor was unable to find the shared buffer after acquiring it for a software POR request.
09	Store loop adapter system status byte. See page 5.11.	A level 7 hardware interrupt was not received from a software POR request.
0A	Store loop adapter system status byte. See page 5.11.	The store loop adapter microprocessor internal diagnostic test failed to complete during the software POR.
0B	Shared buffer	The alternate shared buffer failed.

4684 Store Loop Adapter/A  
Shared Buffer Latch Error Codes and Extended Data

	error codes. See page 5.10.1.	
0C	Shared buffer error codes. See page 5.10.1.	The primary shared buffer failed.
10	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer for a software POR request.
11	Store loop adapter system status byte. See page 5.11.	The software POR request failed.
12	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer for a Read EC Level request.
13	Store loop adapter system status byte. See page 5.11.	The read EC level request failed.
14	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer for terminal quiesce procedure.
15	Store loop adapter system status byte. See page 5.11.	The store loop circuit was open during the terminal quiesce procedure.
16	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer for loop wrap setup.
17	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer while performing the data wrap test.
18	Data message count	Retransmit retry count exhausted.
19	Data message count	Data wrap receive error. See page 5.8.1.
1A	Data message count	Data wrap compare error.
1B	Store loop adapter system status	The 4684 microprocessor was unable to acquire the shared buffer for the offline procedure.

4684 Store Loop Adapter/A  
Shared Buffer Latch Error Codes and Extended Data

	byte. See page 5.11.	
20	Store loop adapter system status byte. See page 5.11.	Timeout while waiting for a level 7 hardware interrupt.
30	Store loop adapter system status byte. See page 5.11.	Timeout while waiting for a response from a request to acquire the shared buffer for a software POR request.
31	Store loop adapter system status byte. See page 5.11.	Timeout while waiting for a response from a software POR request.
32	Store loop adapter system status byte. See page 5.11.	Timeout while waiting for a response from a request to acquire the shared buffer for a read EC level request.
33	Store loop adapter system status byte. See page 5.11.	Timeout while waiting for a response from a read EC level request.
40	Store loop adapter interrupt flag byte. See page 5.14.	A level 7 interrupt was received with unexpected status.
70	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer for a software POR request.
71	Store loop adapter system status byte. See page 5.11.	The software POR request failed.
72	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer for a read EC level request.
73	Store loop adapter system status byte. See page 5.11.	The read EC level request failed.
80	Store loop adapter interrupt flag byte. See page 5.14.	A level 7 interrupt was received when not expected.
90	Store loop adapter interrupt flag byte.	A level 7 interrupt was received when not expected.

4684 Store Loop Adapter/A  
Shared Buffer Latch Error Codes and Extended Data

	See page 5.14.	
94	Store loop adapter interrupt flag byte. See page 5.14.	The 4684 microprocessor was unable to acquire the shared buffer for terminal quiesce procedure.
95	Store loop adapter interrupt flag byte. See page 5.14.	The store loop circuit was open during the terminal quiesce procedure.
96	Store loop adapter interrupt flag byte. See page 5.14.	The 4684 microprocessor was unable to acquire the shared buffer for loop wrap setup.
97	Store loop adapter interrupt flag byte. See page 5.14.	The 4684 microprocessor was unable to acquire the shared buffer while performing the data wrap test.
98	Store loop adapter interrupt flag byte. See page 5.14.	Retransmit retry count exhausted.
99	Store loop adapter interrupt flag byte. See page 5.14.	Data wrap receive error. See page 5.8.1.
9B	Store loop adapter interrupt flag byte. See page 5.14.	The 4684 microprocessor was unable to acquire the shared buffer for the offline procedure.
C0	Store loop adapter interrupt flag byte. See page 5.14.	A level 7 interrupt was received when not expected.
F0	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer for a software POR request.
F1	Store loop adapter system status byte. See page 5.11.	The software POR request failed.
F2	Store loop adapter system status byte. See page 5.11.	The 4684 microprocessor was unable to acquire the shared buffer for a read EC level request.
F3	Store loop adapter system status	The read EC level request failed.

| byte. See |  
| page 5.11. |  
+-----+

5.10 Failure Status Bytes 4 and 5

Subtopics

5.10.1 Shared Buffer Error Codes and Test Patterns

5.10.1 Shared Buffer Error Codes and Test Patterns

This table defines the meaning of failure status bytes 4 and 5 of the store loop adapter failure status bytes.

Table 5-4. Shared Buffer Error Codes and Test Patterns		
Byte 4 Error Code	Byte 5 Test Patter	Definition
00	00	No errors detected.
01	01	Data test pattern failed.
02	02	Data test pattern failed.
03	04	Data test pattern failed.
04	08	Data test pattern failed.
05	10	Data test pattern failed.
06	20	Data test pattern failed.
07	40	Data test pattern failed.
08	80	Data test pattern failed.
09	FE	Data test pattern failed.
0A	FD	Data test pattern failed.
0B	FB	Data test pattern failed.
0C	F7	Data test pattern failed.
0D	EF	Data test pattern failed.
0E	DF	Data test pattern failed.
0F	BF	Data test pattern failed.
10	7F	Data test pattern failed.
11	F1	Buffer address 0400 failed.
12	02	Buffer address 0200 failed.
13	F3	Buffer address 0100 failed.
14	04	Buffer address 0080 failed.
15	F5	Buffer address 0040 failed.
16	06	Buffer address 0020 failed.
17	F7	Buffer address 0010 failed.
18	08	Buffer address 0008 failed.
19	F9	Buffer address 0004 failed.
1A	0A	Buffer address 0002 failed.
1B	FB	Buffer address 0001 failed.
1C	0C	Buffer address 0000 failed.
1D	0E	Buffer address 0400 failed.
1E	FD	Buffer address 0200 failed.
1F	0C	Buffer address 0100 failed.
20	FB	Buffer address 0080 failed.
21	0A	Buffer address 0040 failed.
22	F9	Buffer address 0020 failed.
23	08	Buffer address 0010 failed.

4684 Store Loop Adapter/A  
Shared Buffer Error Codes and Test Patterns

24	F7	Buffer address 0008 failed.
25	06	Buffer address 0004 failed.
26	F5	Buffer address 0002 failed.
27	04	Buffer address 0001 failed.
28	F3	Buffer address 0000 failed.

5.11 Store Loop Adapter System Status Byte

This table describes the bits of the store loop adapter system status byte (SSB). The values in the SSB represent the current state of the store loop adapter hardware.

Table 5-5. Store Loop Adapter System Status Byte	
Bit	Definition
Bit 7 (Read only)	Reserved
Bit 6 (Read/write)	1 = Generate(d) a store loop adapter POR. 0 = Reset the POR mechanism.
Bit 5 (Read/write)	Reserved
Bit 4 (Read only)	Reserved
Bit 3 (Read/write)	1 = Enable the interrupt mechanism. 0 = Disable the interrupt mechanism.
Bit 2 (Read only)	1 = Level 7 interrupt is active. 0 = Level 7 interrupt is inactive.
Bit 1 (Read/write)	1 = Shared buffer access is complete. 0 = Shared buffer return is complete.
Bit 0 (Read/write)	1 = Request(ed) shared buffer access. 0 = Shared buffer return is complete.

## 5.12 Shared Buffer Request Byte

This table describes the bits of the shared buffer request bytes. This byte is updated by the 4684 microprocessor after each access of the message buffer.

Table 5-6. Shared Buffer Request Byte	
Bit	Definition
Bit 7	1 = Diagnostic self-test request.
Bit 6	1 = Read and process the "timer function" bytes.
Bit 5	1 = Read and process the "loop mode" byte.
Bit 4	1 = Process the "transmit message(s)" held in the shared buffer.
Bit 3	1 = Read and process the "timer/transmit function" bytes.
Bit 2	1 = Internal 8051 storage dump request.
Bit 1	1 = Read EC level request.
Bit 0	1 = Read and process the "loop address" bytes.

## 5.13 Shared Buffer Status Byte

This table describes the bits of the shared buffer status byte. This byte is updated by the store loop adapter microprocessor before it interrupts the 4684 microprocessor.

Table 5-7. Shared Buffer Status Byte	
Bit	Definition
Bit 7	1 = The diagnostic self-test is complete.
Bit 6	0 = All commands are complete. 1 = Busy
Bit 5	1 = Poll received.
Bit 4	1 = Loop message received.
Bit 3	1 = An error message is present.
Bit 2	1 = An internal 8051 storage dump is present.
Bit 1	1 = An EC level message is present.
Bit 0	Reserved

5.14 Store Loop Adapter Interrupt Flag Byte

This table describes the bits of the store loop adapter interrupt flag byte. This byte is updated by the software interrupt service routine when a level 7 hardware interrupt occurs.

Table 5-8. Store Loop Adapter Interrupt Flag Byte	
Bit	Definition
Bit 7	1 = The level 7 interrupt is not from the store loop adapter.
Bit 6	1 = An interrupt occurred when not expected (Bit 0 = 0).
Bit 5	1 = More than one interrupt occurred when only one was expected (Bit 0 = 1).
Bit 4	Not used, always zero (0).
Bit 3	Not used, always zero (0).
Bit 2	Not used, always zero (0).
Bit 1	1 = A store loop adapter level 7 hardware interrupt has occurred.
Bit 0	1 = A store loop adapter level 7 hardware interrupt is expected.

Assembly 1: IBM 4684 Store Loop Adapter/A

PICTURE 14

Asm - Index	Part Number	Units	Description
1 - 1	92F5844	AR	Adapter card
- 2	6316840	AR	Adapter cable

Additional Service Aids

Part Number	Units	Description
96X4967	AR	Wrap plug

*B.0 Appendix B. Warranty Information*

Subtopics

B.1 International Business Machines Corporation  
B.2 STATEMENT OF LIMITED WARRANTY

Armonk, New York 10504

**Warranty Exhibit to IBM Statement of Limited Warranty****IBM 4684 Store Loop Adapter/A**

If you purchased this Machine directly from International Business Machines Corporation (IBM) or another IBM organization under an agreement for purchase of IBM Machines, the warranty provisions therein shall prevail and this Warranty Exhibit and the IBM Statement of Limited Warranty (Z125-3744) shall not apply.

If you purchased this Machine from a Remarketer, the warranty service described in the IBM Statement of Limited Warranty is available only for Machines purchased and located in the United States or Puerto Rico.

If you purchased this Machine from a supplier authorized by an IBM organization to market this Machine in other than the United States or Puerto Rico, warranty information is available only from such supplier.

**1. Date of Installation (Warranty start date):**

IBM, and IBM Remarketer or an IBM authorized supplier will supply the Date of Installation to you. The Warranty Period will commence on this Date.

**2. Warranty Duration:**

Three months.

**3. Type of Service:**

IBM On-Site Repair (IOR)

**4. Provider of Warranty Service:**

IBM or Remarketer may provide warranty service for this Machine.

**5. Period of Warranty Service Availability:**

Contact a Remarketer to determine the available periods of warranty service.

Contact IBM for warranty service 24 hours a day, 7 days a week by calling 1-800-428-2569.

This Machine is a Customer Set-Up (CSU) Machine. You are responsible to set up this Machine in accordance with the instructions furnished by IBM.

You may be required to present proof of purchase for this Machine to IBM or a Remarketer to obtain warranty service.

If you have any questions about warranty service, contact a Remarketer for this Machine. You may also call IBM Direct at 1-800-IBM-2468.

```

+-----+
| International Business Machines           | Armonk, New York, 10504 |
| Corporation                               |                         |
+-----+

```

B.2 STATEMENT OF LIMITED WARRANTY

International Business Machines Corporation (IBM) gives you the following limited warranty for this IBM Machine. IBM gives you this limited warranty only if this Machine was originally purchased for use, and not resale, from an IBM Authorized Dealer, IBM Authorized Industry Remarketer or an IBM approved Reseller. The Dealer, Remarketer or Reseller must be authorized or approved by IBM to market this Machine. The Warranty Exhibit to this Statement identifies this Machine and specifies other important information. This Machine will be subject to this Statement of Limited Warranty only if purchased and located in the United States or Puerto Rico.

Subtopics

B.2.1 DEFINITIONS

B.2.2 LIMITED WARRANTIES

B.2.3 Service and Parts Warranty

B.2.4 Types of Service

B.2.5 Additional Provisions for Features and Model Conversions

B.2.6 Additional Provisions for Machine Elements and Accessories

B.2.7 Travel Expense

B.2.8 Services for Additional Charge During the Warranty Period

B.2.9 Other Warranty Provisions and Exclusions

B.2.10 LIMITATION OF REMEDIES

B.2.1 DEFINITIONS

The term "Remarketer" shall mean an IBM Authorized Dealer, IBM Authorized Industry Remarketer or IBM approved Reseller for this Machine unless the context requires individual reference.

The term "Machine" shall mean a machine and/or its features, model conversions, machine elements and accessories unless the context requires individual reference.

The term "failing machine" shall mean a machine or machine element requiring warranty service as initially determined by you and, as applicable, verified by IBM.

The term "exchange machine" shall mean a machine or machine element provided to you by IBM under an Exchange Type of Service.

B.2.2 LIMITED WARRANTIES

A Machine subject to this Statement of Limited Warranty will be 1) newly manufactured by or for IBM from new and serviceable used parts which are equivalent to new in performance in the Machine, 2) assembled by or for IBM from serviceable used parts, or 3) a Machine which has been previously installed.

IBM warrants that on this Machine's Date of Installation it will be in good working order and will conform to IBM's official published specifications. IBM will make these specifications available to you upon request.

The Warranty Period for this Machine commences on its Date of Installation. The Warranty Period duration is specified in the Warranty Exhibit. If the Warranty Period expires on a Friday or Saturday, IBM will extend the Warranty Period so that its last day will be the following Sunday.

IBM or a Remarketer will notify you of the Date of Installation. IBM reserves the right to correct any error in such date.

### B.2.3 Service and Parts Warranty

IBM agrees to provide the availability of warranty service for the duration of the Warranty Period at no additional charge except as set forth in this Statement. IBM will provide warranty service, as required, by 1) repairing this machine, model upgrade or feature addition or 2) exchanging the machine or machine element. IBM will render repair or exchange under one of the Types of Service described in this Statement. IBM will specify the specific Type of Service for this Machine during its Warranty Period in the Warranty Exhibit. For certain Machines, IBM offers a Warranty Option that provides an alternate method of obtaining warranty service under another Type of Service. Any such Warranty Option is available under the IBM Maintenance Agreement.

IBM shall have full, free and safe access to this Machine to provide On-Site Types of Service. You shall promptly inform IBM of any change in this Machine's location during its Warranty Period.

You are responsible to initially determine that the machine or machine element requires warranty service. Before requesting such service, you shall follow IBM's problem determination, problem analysis and service request procedures.

You are responsible to remove and control funds contained in a Machine. IBM will service a Machine containing funds only when you cannot open the cash container. If so, you will remove the funds as soon as the container is, or can be, opened.

IBM will render a Repair or Exchange Type of Service only when you present a failing machine to IBM.

Under a Repair Type of Service, IBM will provide remedial maintenance to restore the Machine to good working order. IBM may also provide preventive maintenance based on the specific needs of the Machine as determined by IBM. IBM may also lubricate, adjust and replace parts when IBM considers it necessary. IBM will install parts, which may be used parts, on an exchange basis. IBM will acquire title to the replaced parts. You are responsible to remove or protect all programs, data and removable storage media before IBM repairs the Machine.

Under an Exchange Type of Service, IBM will provide an exchange machine which may not be new but will be in good working order. You will acquire title to it at the time of exchange. IBM will acquire title to the failing machine at the time of exchange. IBM reserves the right to verify that a failing machine is acceptable for exchange. You are responsible to remove all non-IBM parts, options, alterations and attachments before you present a failing machine for exchange. You give up all rights to any such items not removed. You will not present IBM a failing machine for exchange which is defaced, altered, in need of a repair not included in warranty service, or damaged beyond repair. IBM will inspect the failing machine to determine if the failing machine is in such condition. If so, IBM will nullify the exchange and each party will return to the other the machine or machine element in its possession. You will ensure that a failing machine is free of any encumbrances at the time you present it to IBM under an Exchange Type of Service.

The Period of Warranty Service is 24 hours a day, 7 days a week for IBM On-Site Types of Service. The Period of Warranty Service for all other Types of Service is the normal business hours of the IBM designated location.

If you request, and IBM provides, an On-Site Type of Service in place of the Type of Service then in effect, you shall pay IBM's then generally available charge for the service provided.

Warranty service does not assure uninterrupted operation of this Machine.

During the Warranty Period, IBM will control and install engineering changes IBM determines to be applicable to this Machine. You may, by providing notice subject to IBM's written confirmation, elect to have only IBM designated mandatory engineering changes installed on this Machine.

#### B.2.4 Types of Service

IBM On-Site Repair (IOR): IBM will provide warranty service for the failing machine at your location.

IBM On-Site Exchange (IOE): IBM will 1) deliver the exchange machine to your location, 2) disconnect the failing machine, 3) connect the exchange machine, 4) verify its operation, and 5) remove the failing machine from your location.

Customer On-Site Exchange (COE): IBM will have an exchange machine delivered to your location. You will 1) disconnect the failing machine and prepare it for shipment to IBM, 2) connect the exchange machine, and 3) verify its operation. You will follow IBM's instructions regarding shipment of the failing machine to IBM. IBM will pay the shipment expense.

Customer Carry-In Repair (CCR): You will 1) deliver the failing machine to an IBM designated location, 2) pick up the machine or machine element, following any repairs, and take it to your location, 3) connect it, and 4) verify its operation.

In place of such delivery and pickup, you may ship the failing machine, prepaid, in the original shipping container, or equivalent, to an IBM location designated to receive such shipment. Following any repairs, IBM will ship the machine or machine element to your location, prepaid, within the United States or Puerto Rico.

Customer Carry-In Exchange (CCE): You will 1) deliver the failing machine to an IBM designated location, 2) pick up the exchange machine and take it to your location, 3) connect it, and 4) verify its operation.

In place of such delivery and pickup, you may ship the failing machine, prepaid, in the original shipping container, or equivalent, to an IBM location designated to receive such shipment. Following receipt of the failing machine, IBM will ship the exchange machine to your location, prepaid, within the United States or Puerto Rico.

You are responsible for risk of loss of, or damage to, the Machine during the period such Machine is in transit to and from IBM. However, IBM is responsible for risk of loss of, or damage to, 1) IBM-owned Machines and/or 2) a Machine owned by other than IBM while in IBM's possession or in transit from IBM to you by an IBM-selected carrier whose charges IBM prepays. In addition, IBM is responsible for loss or damage due to IBM's negligence.

*B.2.5 Additional Provisions for Features and Model Conversions*

IBM's warranty for each feature addition or model upgrade requires that the machine on which such addition or upgrade is installed meets certain conditions. The machine must 1) be at a proper engineering-change level, as IBM determines, 2) be the specific serial-numbered machine for which you ordered such addition or upgrade, and 3) have been modified only with changes obtained from IBM specifically for that serial-numbered machine. If these conditions are not met, IBM will attempt to install a non-CSU feature addition and/or model upgrade on the machine. If such attempt results in a correctly functioning machine, this Statement will apply. If such attempt results in an incorrectly functioning machine, upon your request, IBM will remove the feature addition and/or model upgrade and restore the machine to its prior condition. In such case, IBM will invoice you IBM's generally available charges, including travel expenses. If the feature addition or model upgrade did not involve the removal of parts which became IBM's property, such feature addition or model upgrade remains your property. If the feature addition or model upgrade involved the removal of parts which became IBM's property, such feature addition or model upgrade becomes IBM's property and the restored parts become your property.

IBM will provide a three-month parts warranty for additional parts supplied by IBM for a feature removal, model downgrade or reinstallation of a previously purchased feature or model conversion.

*B.2.6 Additional Provisions for Machine Elements and Accessories*

A machine element, which you separately purchased, or an accessory has a three-month Warranty Period unless IBM specifies a longer duration. During the Warranty Period, you will remove any such machine element or accessory which fails in normal use. You will then ship it, prepaid, to the IBM location designated to receive such shipment. IBM will repair or replace, at its option, such machine element or accessory. IBM's shipment to you will be prepaid within the United States or Puerto Rico.

*B.2.7 Travel Expense*

There will be no additional charge for travel expense associated with warranty service except when the site at which the Machine is located is inaccessible to the IBM service representative by both private automobile and scheduled public transportation.

*B.2.8 Services for Additional Charge During the Warranty Period*

Warranty service does not include repair of certain Machine failures. These failures are those which are caused by an unsuitable environment, accident, disaster, transportation, vandalism, misuse, abuse, another product or device not under IBM warranty or IBM agreement service, non-IBM modification, or service of the Machine by other than IBM. In addition, warranty service does not include inspection of the Machine, including inspection of an altered Machine, or repair of damage caused by use of, inadequate use of, or failure to use, supplies. If service not included in warranty service is available, and IBM provides such service, it will be provided for an additional charge. IBM shall determine such charge by using IBM's 1) then generally available hourly service rates and minimum charges for service time, including travel and waiting time, 2) parts and material prices then generally in effect, and 3) charges for travel and shipping expense, all as applicable.

*B.2.9 Other Warranty Provisions and Exclusions*

This limited warranty does not include any service which is impractical for IBM to render because of alterations in, or attachments to, this Machine. IBM will replace a part not provided by IBM for this Machine only with a directly interchangeable IBM part. If so, IBM will charge you as described in the preceding paragraph. IBM will not replace any part which is included in an alteration.

If you transfer this Machine to another user, IBM will provide the availability of warranty service under this Statement to that user. Such warranty service will be available for the remainder of the Warranty Period. Therefore, you should transfer the proof of purchase and this Statement to that user.

**THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

*B.2.10 LIMITATION OF REMEDIES*

Your sole remedy under this Statement of Limited Warranty is set forth in this Section. For any claim concerning performance or nonperformance by IBM, an IBM Authorized Dealer, or an IBM Authorized Industry Remarketer for this Machine under this Statement of Limited Warranty, you may recover actual damages up to the limit set forth in the following paragraph.

The limit of IBM's liability for actual damages to you for an individual event based on any cause whatsoever shall be the greater of 1) \$100,000 or 2) the amount you paid for the Machine which caused the damages. This limitation of liability will not apply to claims for personal injury or damage to real property or tangible personal property caused by IBM's negligence. In no event will IBM be liable to you for any damages caused by your failure to fulfill your responsibilities under this Statement of Limited Warranty. In no event will IBM be liable for any lost profits, lost savings, incidental damages, or other consequential damages. This is true even if you advised IBM or a Remarketer of the possibility of such damages. IBM is not liable for any claim by you based on any third party claim.

**A**

adapter  
  block diagram 5.3  
  cable diagram 5.1  
  error code 5.7.1  
  failure status byte 0 5.7.1  
  failure status byte 1 5.8.1  
  failure status bytes 5.6  
  failure status bytes 2 and 3 5.9.1  
  failure status bytes 4 and 5 5.10.1  
  interrupt flag byte 5.14  
  loop relay diagram 5.2  
  microprocessor status codes 5.8.1  
  POST test errors 5.5  
  shared buffer errors and test patterns 5.10.1  
  shared buffer latch and extended data 5.9.1  
  shared buffer request byte 5.12  
  shared buffer status byte 5.13  
  storage map 5.4  
  system status byte 5.11

anti-static bag 2.1

**C**

cable diagram 5.1  
catalog, parts A.0  
CAUTION notice  
  use grounded receptacle FRONT\_3 2.1  
  use 3-wire power cord FRONT\_3 2.1  
configuration 3.0

**D**

DANGER notice  
  cabling during electrical storms FRONT\_3 3.0 4.1  
diagnostic test  
  failure 4.2.1 4.3.1  
  symptom 4.2.1 4.3.1

## diagram

  adapter storage map 5.4  
  cable wiring 5.1  
  loop adapter, block 5.3  
  loop relay 5.2

discharge, static 2.1

**E**

error code, adapter 5.7.1  
extended data, shared buffer latch 5.9.1

**F**

failure status  
  byte 0 5.7.1  
  byte 1 5.8.1  
  bytes 5.6  
  bytes 2 and 3 5.9.1  
  bytes 4 and 5 5.10.1

finding problems 4.0

**I**

## information

  configuration 3.0  
  finding problems 4.0  
  installation 2.0  
  introduction 1.0  
  parts catalog A.0  
  problem determination 4.0  
  technical reference 5.0  
  testing 3.0  
  warranty B.0

installation instructions 2.0

interrupt flag byte 5.14

introduction 1.0

**L**

limited warranty B.0

## loop adapter

  diagram 5.3  
  error code 5.7.1  
  interrupt flag byte 5.14  
  microprocessor status codes 5.8.1  
  POST test errors 5.5  
  shared buffer errors and test patterns 5.10.1  
  shared buffer latch and extended data 5.9.1  
  shared buffer request byte 5.12  
  shared buffer status byte 5.13  
  status byte 0 5.7.1  
  status byte 1 5.8.1  
  status bytes 5.6  
  status bytes 2 and 3 5.9.1  
  status bytes 4 and 5 5.10.1  
  storage map 5.4  
  system status byte 5.11

loop relay diagram 5.2

**M**

maintenance

parts catalog A.0

message

CC000 4.2

C0000 4.2

C4000 4.2

C8000 4.2

D0000 4.2

D4000 4.2

62xx 4.2.1

6210 4.3.1

6270 4.3.1

microprocessor status codes, adapter 5.8.1

**N**

notices

CAUTION

use grounded receptacle FRONT\_3 2.1

use 3-wire power cord FRONT\_3 2.1

DANGER

cabling during electrical storms FRONT\_3 3.0 4.1

Warning

FCC statement NOTICES

static discharge 2.1

**P**

parts catalog A.0

POST test errors 5.5

power-on self-test

failure 4.2

symptom 4.2

problem determination 4.0

publications, related 1.1

**R**

related publications 1.1

relay diagram, loop 5.2

running tests 3.0

**S**

shared buffer

errors and test patterns 5.10.1

latch and extended data 5.9.1

request byte 5.12

status byte 5.13

static discharge 2.1

status bytes

adapter failure 5.6

byte 0 5.7.1

byte 1 5.8.1

bytes 2 and 3 5.9.1

bytes 4 and 5 5.10.1

interrupt flag 5.14

POST test errors 5.5

shared buffer 5.13

shared buffer request 5.12

system 5.11

storage map, loop adapter 5.4

store loop adapter diagram, block 5.3

symptom message

CC000 4.2

C0000 4.2

C4000 4.2

C8000 4.2

D0000 4.2

D4000 4.2

62xx 4.2.1

6210 4.3.1

6270 4.3.1

system status byte 5.11

**T**

technical reference 5.0

test patterns, shared buffer errors 5.10.1

testing 3.0

**W**

Warning notice

FCC statement NOTICES

static discharge 2.1

warranty information B.0

wiring diagram, cable 5.1