


- 11** Attach the drive in bay 3 of the drive-support bracket.



- 12** If you installed a drive other than a hard disk drive, remove the bay panel for bay 3.

Notes:

- a. To remove the front panel, tap lightly against each end of the panel using a small tool.
- b. You might want to save the panel in case you need to use it again.

