FRONT

PICTURE 1

March 21, 1990

This pamphlet provides external devices parts information for servicers and should be used with the IBM(*) Personal System/2(*) Hardware Maintenance Reference manual (part number 15F2190) and the IBM Personal System/2 Hardware Maintenance Service manual (part number 15F2200).

Part Number 64F4022

Form Number S64F-4022-00

First Edition (March 1990)

The following paragraph does not apply to the United Kingdom or any country where such provisions are inconsistent with local law:
INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time.

It is possible that this publication may contain reference to, or information about, IBM products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that IBM intends to announce such IBM products, programming, or services in your country.

Requests for technical information about IBM products should be made to your IBM Authorized Dealer or your IBM Marketing Representative.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to the IBM Director of Commercial Relations, IBM Corporation, Armonk NY 10504.

| Copyright International Business Machines Corporation 1990. All rights reserved.

Note to US Government users-Documentation related to Restricted rights-Use, duplication, or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

IBM PS/2 External Devices Parts Catalog Special Notices

FRONT 1 Special Notices

References in this publication to IBM products, programs, or services do not imply that IBM intends to make these available in all countries in which IBM operates. Any reference to an IBM product, program or service is not intended to state or imply that only IBM's product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any of IBM's intellectual property rights or other legally protectible rights may be used instead of the IBM product, program, or service. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by IBM, are the user's responsibility.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to the IBM Director of Commercial Relations, IBM Corporation, Purchase, NY 10577.

The following terms, denoted by an asterisk (*) in this publication, are trademarks of the IBM Corporation in the United States and/or other countries:

IBM

Personal System/2.

LIMITED WARRANTY - IBM SERVICE PARTS

(United States and Puerto Rico)

The International Business Machines Corporation warrants that each IBM Service Part will be free from defects in material and workmanship under conditions of normal use for a period of three months from the date of purchase from IBM or an IBM Authorized Dealer. Service Parts may be other than new but will be in good working order. Should an IBM Service Part fail to be free from defects in materials or workmanship during the three month warranty period, IBM will, at its option, repair or replace this Service Part at no additional charge in the United States or Puerto Rico. All replaced Service Parts will become the property of IBM. This limited warranty does not include service to repair damage to the Service Part resulting from accident, disaster, misuse, abuse, or non-IBM modification of the Product.

Limited Warranty service may be obtained by delivering the defective Service Part during the three month warranty period to the IBM or IBM Authorized Dealer purchase location in the United States or Puerto Rico. A dated proof of purchase from IBM or an IBM Authorized Dealer must accompany the claim. Contact IBM by writing to IBM Corporation Parts Order Center, P.O. Box 1234, 123 New Circle Road, Lexington, Kentucky 40511 for further information.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS SERVICE PART, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO A PERIOD OF THREE MONTHS FROM THE DATE OF PURCHASE, AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THIS PERIOD.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

If this Service Part is defective in materials or workmanship under conditions of normal use, as warranted above, your sole remedy shall be repair or replacement as provided above. In no event will IBM be liable to you for any damages, including lost profits, lost savings or other incidental or consequential damages arising out of the use of or inability to use such Service Part, even if IBM or an IBM Authorized Dealer has been advised of the possibility of such damages, or for any claim by you based on any third party claim.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

IBM PS/2 External Devices Parts Catalog Table of Contents

С	CONTENTS Table	of Contents
F	RONT_1	Special Notices
C	CONTENTS	Table of Contents
1	0	How To Use This Parts Catalog
1	1	Example of a Parts List
2	2.0	Monochrome Display (8503)
3	3.0	Monochrome Display (8506)
4	1.0	Monochrome Display (8507)
5	5.0	Monochrome Display (8508)
6	5.0	Color Display (8512)
7	'.0	Color Display (8513)
8	3.0	Color Display (8514)
9	0.0	Keyboard (101/102 Key)
1	.0.0	Keybutton Kits (101/102 Key)
1	1.0	Space Saving Keyboard (84/85 Key)
1	2.0	Space Saving Keybutton Kits (84/85 Key)
1	.3.0	CD-ROM
1	4.0	Mouse
1	.5.0	5.25-Inch External Diskette Drive
1	.6.0	Special Products
1	7.0	Power Cords

IBM PS/2 External Devices Parts Catalog How To Use This Parts Catalog

1.0 How To Use This Parts Catalog

SIMILAR ASSEMBLIES: If two assemblies contain a majority of identical parts, they are broken down on the same list. Parts peculiar to one or the other of the assemblies are listed separately and identified by description.

 ${\tt AR\colon}$ (As Required) indicates that the quantity is not the same for all machines.

R: (Restricted) indicates that the part has a restricted availability.

INDENTURE the indenture is marked by a series of dots located before the parts description. The indenture indicates the relationship of a part to the next higher assembly. For example:

Indenture Relationship of Parts

(No dot)	Main Assembly
(One dot)	Detail parts of a main assembly
(One dot)	Subassembly of the main assembly
(Two dot)	Detail part of a one-dot subassembly
(Two dot)	Subassembly of a one-dot subassembly

Subtopics

1.1 Example of a Parts List

IBM PS/2 External Devices Parts Catalog Example of a Parts List

1.1 Example of a Parts List

System Unit

Cover 72X8501
Front Bezel/Logo (R) 72X8502
Miscellaneous Hardware Kit (AR) 72X8580
Knob Assembly, Fixed Disk
Drive Support Structure
Knob
Washer

IBM PS/2 External Devices Parts Catalog Monochrome Display (8503)

2.0 Monochrome Display (8503)

Display Assembly 110/120 Volt	68X3045
Display Assembly 220/240 Volt	
(Northern Hemisphere)	68X3046
Display Assembly 220/240 Volt	
(Southern Hemisphere)	72X7878
Tilt/Swivel Stand	68X3061
Shipping Material (AR)	68X3047
(Box, Cushions, Poly Bag, Dryer)	
Display serial numbers 72-0,000,001 through	72-4,999,999.
CRT/Yoke Assembly (R)	68X3028
Power Supply Assembly (220/240 Volt) (R)	68X3089
Power Supply Assembly (110/120 Volt) (R)	72X7872
Contrast/Brightness Control Assembly (R)	72X7873
Power on LED (R)	72X7876
Main PC Board Assembly (R)	72X7874
Video Driver Board (R)	72X7875
Signal Cable (R)	68X3040
Cover Set Complete 110/120 Volt (R)	68X3041
(Exchange Basis Only)	
Cover Set Complete 220/240 Volt (R)	68X3043
Northern Hemisphere (Exchange Basis Only)	
Cover Set Complete 220/240 Volt (R)	68X3044
Southern Hemisphere (Exchange Basis Only)	
Display Foot	68X3075
Magnetic Shield	90X6657
Display serial numbers 72-5,000,000 through	72-9,999,999.
Cover Set Complete 110/120 Volt (R)	72X7680
(Exchange Basis Only)	
Cover Set Complete 220/240 Volt (R)	72X7682
Northern Hemisphere (Exchange Basis Only)	
Cover Set Complete 220/240 Volt (R)	72X7684
Southern Hemisphere (Exchange Basis Only)	
Signal Cable (R)	72X7686
Main PC Board Assembly (R)	72X7687
Brightness and Contrast Controls	
Power Supply Assembly 110/120 Volt (R)	72X7688
Power Supply Assembly 220/240 Volt (R)	72X7689
(Northern/Southern Hemisphere)	
CRT/Yoke Assembly (R)	72X7690
Power On LED (R)	72X7691
Display Foot	72X7692
Power Switch (R)	72X7693
Video Driver Card (R)	72X7695
. ,	

IBM PS/2 External Devices Parts Catalog Monochrome Display (8506)

3.0 Monochrome Display (8506)

110/125	Vac	c (US/Car	nada)			39F8087	
110/125	or	200/240	Vac	(Northern	Hemisphere)		39F8088
110/125	or	220/240	Vac	(Southern	Hemisphere)		39F8089

IBM PS/2 External Devices Parts Catalog Monochrome Display (8507)

4.0 Monochrome Display (8507)

Display Assembly 110/120 or 220/240 Vac (Universal Model) 6247808

Packaging Materials 6247847

IBM PS/2 External Devices Parts Catalog Monochrome Display (8508)

5.0 Monochrome Display (8508)

1	10/125	Vac	c (US/Cai	nada)		6247838	
1	10/125	or	200/240	Vac	(Northern	Hemisphere)	39F8067
1	10/125	or	220/240	Vac	(Southern	Hemisphere)	39F8068

IBM PS/2 External Devices Parts Catalog Color Display (8512)

6.0 Color Display (8512)

Power Supply

Control Bridge (R) Signal Cable Assembly

Display Foot

Cover Set Complete (R)(Exchange Basis Only)

6.0 Color Display (8512)		
Display Assembly, 110/120 Volt	61X8924	
Display Assembly, 220/240 Volt	61X8928	
(Northern Hemisphere)	01110020	
Display Assembly, 220/240 Volt	61X8927	
(Southern Hemisphere)	01110727	
Tilt/Swivel Stand	61X8925	
Shipping Material (AR)(Display)	72X7976	
Package Guidelines (AR)	72X8605	
Shipping Carton (AR)	72X7977	
Shipping Cushion, Front (AR)	72X7957	
Shipping Cushion, Back (AR)	72X7958	
Shipping Bag (AR)	72X7959	
Shipping Tape (AR)	6937012	
Shipping Material (AR)(Stand)	72X7978	
Package Guidelines (AR)	72X8605	
Shipping Carton (AR)	72X7979	
Shipping Cushions (Qty 2) (AR)	72X7967	
Shipping Bag (AR)	72X7968	
Shipping Tape (AR)	6937012	
Display serial numbers beginning with 72.		
Power Switch (R)	61X8892	
Power-On Indicator (R)	61X8895	
Contrast and Brightness Control Assembly (R)	61X8893
Video Amplifier Assembly (R)	61X8884	
Main PC Board Assembly (R)	61X8885	
	61X8931	
Power Supply (220/240 Volt) (R)	61X8883	
CRT/Yoke Assembly (R) 110/120 Volt,	61X8886	
220/240 Volt Northern Hemisphere)		
CRT/Yoke Assembly (R) 220/240 Volt	61X8887	
(Southern Hemisphere)		
Signal Cable Assembly (R)	61X8888	
	61X8891	
Rubber Foot (Qty 4)		
Fasteners and Washers		
Cover Set Complete 110/120 Volt (R)	61X8932	
(Exchange Basis Only)		
Golom Dignley (9512) (gentinged)		
<pre>Color Display (8512) (continued) Cover Set Complete (R)(Exchange Basis Only)</pre>		61X8889
Northern Hemisphere		0170003
Cover Set Complete (R)(Exchange Basis Only)		61X8890
Southern Hemisphere		0170030
Display serial numbers beginning with 23 or	55	
CRT/Yoke Assembly (R)(110/120 Volt,	75X8932	
220/240 Volt Northern Hemisphere)	,5110552	
Low Voltage Card Assembly (110/120 Volt)	75X8933	
Contrast and Brightness Control Assembl		
Switch Assembly	-	
Power Supply		
High Voltage Card Assembly (220/240 Volt)(R)	75X8934
Contrast and Brightness Control Assembl		
Switch Assembly		
Dower Supply		

75X8935

75X9131 75X9132 75X8931

IBM PS/2 External Devices Parts Catalog Color Display (8513)

7.0 Color Display (8513)

7.0 Color Display (8513)		
Display Assembly, 110/120 Volt	68X3088	
Display Assembly, 220/240 Volt	72X7870	
(Northern Hemisphere)	, 211, 0, 0	
Display Assembly, 220/240 Volt	72X7877	
(Southern Hemisphere)	7227077	
Color Display Stand	68X3061	
Shipping Material (AR)	72X7871	
(Box, Cushions, Poly Bag, Dryer)		
Display serial numbers beginning with 72.	6032062	
CRT/Yoke/Dag Strap Assembly (R) 110/120	68X3063	
Volt, 220/240 Volt (Northern Hemisphere)		
CRT/Yoke/Dag Strap Assembly (R)	68X3064	
220/240 Volt (Southern Hemisphere)		
Power Supply Assembly 110/120 Volt (R)	68X3065	
Signal Cable		
Strain Relief		
Power Supply Assembly 220/240 Volt (R)	68X3066	
Signal Cable		
Strain Relief		
Contrast/Brightness Control Assembly (R)	68X3067	
Power On LED (R)	68X3068	
Main Circuit Board/Video Driver Board	68X3069	
- Metal Chassis (R)		
Signal Cable (R)	68X3070	
Signal Casis (II)	00115070	
Color Display (8513) (continued)		
<pre>Color Display (8513) (continued) Cover Set Complete, 110/120 Volt (R)</pre>	68X3072	
	68X3072	
Cover Set Complete, 110/120 Volt (R)	68X3072 72X7868	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only)		
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only)		
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R)	72X7868	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only)	72X7868 72X7869	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R)	72X7868 72X7869 68X3073	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R)	72X7868 72X7869 68X3073 68X3098	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R)	72X7868 72X7869 68X3073 68X3098 72X7865	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075	75×8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075	75X8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075	75X8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display Serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075	75x8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075	75x8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075	75X8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55.	75X8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or SCT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt) Card Assembly, 220/240 Volt (R)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075	75X8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt) Card Assembly, 220/240 Volt (R) (Northern Hemisphere)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55.	75X8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt) Card Assembly, 220/240 Volt (R) (Northern Hemisphere) Brightness and Contrast Controls	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55.	75x8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or (CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly, 220/240 Volt (R) (Northern Hemisphere) Brightness and Contrast Controls Switch Assembly	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55.	75X8924
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or (CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt) Card Assembly, 220/240 Volt (R) (Northern Hemisphere) Brightness and Contrast Controls Switch Assembly Power Supply (220/240 Volt)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55.	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt) Card Assembly, 220/240 Volt (R) (Northern Hemisphere) Brightness and Contrast Controls Switch Assembly Power Supply (220/240 Volt) Cover Set Complete (R)(Exchange Basis Only)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55. 75X8925	75x8924 75x8927
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt) Card Assembly, 220/240 Volt (R) (Northern Hemisphere) Brightness and Contrast Controls Switch Assembly Power Supply (220/240 Volt) Cover Set Complete (R)(Exchange Basis Only) Control Bridge (R)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55.	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt) Card Assembly, 220/240 Volt (R) (Northern Hemisphere) Brightness and Contrast Controls Switch Assembly Power Supply (220/240 Volt) Cover Set Complete (R)(Exchange Basis Only)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55. 75X8925	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt) Card Assembly, 220/240 Volt (R) (Northern Hemisphere) Brightness and Contrast Controls Switch Assembly Power Supply (220/240 Volt) Cover Set Complete (R)(Exchange Basis Only) Control Bridge (R)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55. 75X8925	
Cover Set Complete, 110/120 Volt (R) (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Northern Hemisphere (Exchange Basis Only) Cover Set Complete, 220/240 Volt (R) Southern Hemisphere (Exchange Basis Only) Power Switch Assembly (R) Degaussing Coil, 110/120 Volt (R) Degaussing Coil, 220/240 Volt (R) Display Foot Display serial numbers beginning with 23 or CRT/Yoke Assembly (R) (Northern Hemisphere) Degaussing Coil/Dag Strap Assembly Card Assembly, 110/220 Volt (R) Brightness and Contrast Controls Switch Assembly Power Supply (110/120 Volt) Card Assembly, 220/240 Volt (R) (Northern Hemisphere) Brightness and Contrast Controls Switch Assembly Power Supply (220/240 Volt) Cover Set Complete (R)(Exchange Basis Only) Control Bridge (R) Signal Cable (R)	72X7868 72X7869 68X3073 68X3098 72X7865 68X3075 55. 75X8925 75X8926	

IBM PS/2 External Devices Parts Catalog Color Display (8514)

8.0 Color Display (8514)

Display Assembly, 110/120 Volt	75X5945
Display Assembly, 220/240 Volt	75X5946
(Northern Hemisphere)	
Display Assembly, 220/240 Volt	75X5947
(Southern Hemisphere)	
Tilt/Swivel Stand	75X5907
CRT/Yoke Assembly (R)(Northern Hemisphere)	75X5908
CRT/Yoke Assembly (R)(Southern Hemisphere)	75X5909
Power Supply Assembly, 110/120 Volt (R)	75X5910
Power Supply Assembly, 220/240 Volt (R)	75X5911
Analog and Video Card Assembly (R)	75X5912
Cover (R)	75X5914
Bezel (R)	75X5915
Brightness/Contrast Control Assembly (R)	75X5916
LED Assembly (R)	75X5917
Signal Cable Assembly (R)	75X5918
Degauss Coil Assembly (R)	75X5919
Metal Cover Kit (R)	75X5928
Kit, Miscellaneous Hardware (R)	75X5921
Package Container (AR)	75X5932
Shipping Material (AR)	75X8288
(Box, Cushions, Poly Bag, Dryer)	

9.0 Keyboard (101/102 Key)

Keyboard (w/o cable)(R), Belgian	1392012
Keyboard (w/o cable)(R), Canadian French	1392011
<pre>Keyboard (w/o cable)(R), Danish</pre>	1392005
<pre>Keyboard (w/o cable)(R), Dutch</pre>	1392013
<pre>Keyboard (w/o cable)(R), French</pre>	1392000
<pre>Keyboard (w/o cable)(R), German</pre>	1392001
<pre>Keyboard (w/o cable)(R), Italian</pre>	1392002
<pre>Keyboard (w/o cable)(R), Norwegian</pre>	1392007
<pre>Keyboard (w/o cable)(R), Portuguese</pre>	1392008
<pre>Keyboard (w/o cable)(R), Spanish</pre>	1392003
<pre>Keyboard (w/o cable)(R), Spanish/Latin</pre>	1392015
<pre>Keyboard (w/o cable)(R), Swedish</pre>	1392009
<pre>Keyboard (w/o cable)(R), Swiss/French/</pre>	1392010
German	
<pre>Keyboard (w/o cable)(R), U.K. English</pre>	1392004
Keyboard (w/o cable) U.S. English	1392090
Keypad Assembly (R), Belgian	1392023
Keypad Assembly (R), Canadian French	1392022
Keypad Assembly (R), Danish	1392016
Keypad Assembly (R), Dutch	1392024
Keypad Assembly (R), French	6447041
Keypad Assembly (R), German	6447042
Keypad Assembly (R), Italian	6447043
Keypad Assembly (R), Norwegian	1392018
Keypad Assembly (R), Portuguese	1392019
Keypad Assembly (R), Spanish	6447044
Keypad Assembly (R), Spanish/Latin	1392025
Keypad Assembly (R), Swedish	1392020
Keypad Assembly (R), Swiss/French/German	1392021
Keypad Assembly (R), U.K. English	6447040
Keypad Assembly (R), U.S. English	6447039
Circuit Board Assembly (R)	6447052
(Exchange Basis Only)	
Cover Assembly (R)(Exchange Basis Only)	1392036
Miscellaneous Parts Kit (AR)	6447056
Foot Adjustable	
Screws, Cover	
Screw, Ground	
Nut	
Lock Washer	
Tool (For Key Cap Removal)	6110464
Note: For $101/102$ -key cable assembly, see	the
parts section of the Hardware Maintenance	
Service pamphlet for the system you are ser	vicing.

IBM PS/2 External Devices Parts Catalog Keybutton Kits (101/102 Key)

10.0 Keybutton Kits (101/102 Key)

Keybutton	Kits	(R),	Belgian	1392033	
Keybutton	Kits	(R),	Canadian French	1392032	
Keybutton	Kits	(R),	Danish	1392026	
Keybutton	Kits	(R),	Dutch	1392034	
Keybutton	Kits	(R),	French	6447047	
Keybutton	Kits	(R),	German	6447048	
Keybutton	Kits	(R),	Italian	6447049	
Keybutton	Kits	(R),	Norwegian	1392028	
Keybutton	Kits	(R),	Portuguese	1392029	
Keybutton	Kits	(R),	Spanish	6447050	
Keybutton	Kits	(R),	Spanish / Latin	1392035	
Keybutton	Kits	(R),	Swedish	1392030	
Keybutton	Kits	(R),	Swiss / French / German		1392031
Keybutton	Kits	(R),	U.K. English	6447046	
Keybutton	Kits,	U.S.	. English	6447045	

IBM PS/2 External Devices Parts Catalog Space Saving Keyboard (84/85 Key)

11.0 Space Saving Keyboard (84/85 Key)

Keyboard (w/o cable), Canadian French	1391992
Keyboard (w/o cable), Spanish/Latin	1391993
Keyboard (w/o cable), U.S. English	1391987
Keypad Assembly (R), Canadian French	1391985
Keypad Assembly (R), Spanish/Latin	1391986
Keypad Assembly (R), U.S. English	1392041
Circuit Board Assembly (R)	1391984
Cover Assembly (R)	1391979
Miscellaneous Parts Kit (AR)	6447056
Foot Adjustable	
Screws, Cover	
Screw, Ground	
Nut, Lock Washer	
Cable Assembly, External	1393082
Foot Adjustable (R) (Qty 2)	6447054
Tool (For Key Cap Removal)	6110464

IBM PS/2 External Devices Parts Catalog Space Saving Keybutton Kits (84/85 Key)

12.0 Space Saving Keybutton Kits (84/85 Key)

Keybutton Kit (R), Canadian French1391982Keybutton Kit (R), Spanish / Latin1391983Keybutton Kit, U.S. English1391981

Note: Each kit contains a complete set of

keybuttons (spacebar included).

IBM PS/2 External Devices Parts Catalog CD-ROM

13.0 CD-ROM

Internal CD-ROM Drive	53F3422
Terminators (two) (for 53F3422)	59F3530
Rail Kit (for 53F3422)	34F0041
Ground Wire - Included in Misc Parts Kit	72X8579
Power Cable (single)	72X8521
Signal Cable (single)	34F0043

IBM PS/2 External Devices Parts Catalog Mouse

14.0 Mouse

Mouse				61X8923
Mouse	Ball	and	Pop-Off Retainer	33F8461
Mouse	Ball	and	Twist-Off Retainer	33F8462

IBM PS/2 External Devices Parts Catalog 5.25-Inch External Diskette Drive

15.0 5.25-Inch External Diskette Drive

360KB External Diskette Drive (4869-001)	72X6759
360KB External Diskette Drive (4869-501)	72X6768
360KB Feature Group with Adapter	72X6758
Diskette Drive (R)	72X6771
Power Supply (R)	72X6769
Adapter	72X6757
Cable	27F4211
Drive Connector Assembly	
1.2MB External Diskette Drive (4869-002)	15F7993
1.2MB External Diskette Drive (4869-502)	15F7994
Diskette Drive (R)	15F7995
Power Supply (R)	72X6769
1.2MB 5.25-inch Diskette Adapter/A	15F7996

IBM PS/2 External Devices Parts Catalog Special Products

16.0 Special Products

PhoneCommunicator Adapter	33F4846
PhoneCommunicator Cable (Black-L)	57F1261
PhoneCommunicator Cable (Black-S)	57F1262
PhoneCommunicator Cable (Beige-L)	57F1263
PhoneCommunicator Cable (Beige-S)	57F1264
Screen Reader Adapter	33F4842
Screen Reader Keypad	1393515
Screen Reader Keypad Cable	72X8537
SpeechViewer Adapter	15F8511
Test Plug (for 15F8511)	15F8512
Speech Control Assembly	61X8934

IBM PS/2 External Devices Parts Catalog Power Cords

17.0 Power Cords

Warning: Use the power cord certified for	vour country
Power Cord, Displays, for:	68X3071
Colombia, U.S., Venezuela	
Power Cord, System Unit, for:	62X1045
Colombia, U.S., Venezuela	
Power Cord, System Unit, for:	8529341
Hong Kong, Singapore, U.K.	
Power Cord, System Unit, for:	8529281
France, Germany, Spain	
Power Cord, System Unit, for:	8529282
Italy	
Power Cord, System Unit, for:	8529284
Australia, New Zealand	

Printed in the United States of America