



Timney® Remington 788 Trigger Installation Instructions

Please read these instructions before you install your new Timney® trigger

1. Unload the rifle, making sure the chamber and the magazine are empty.

Remove the bolt. Remove the screws that hold the action to the stock, now remove action from the stock.

2. To remove the factory trigger you will need to loosen the trigger mounting screw ① and drive out the roll pin ⑤ that's holding the trigger assembly to the receiver (keep this pin, you'll need it later to install your Timney® trigger).

3. Attach Timney® trigger to the action with the roll pin at ⑤ and tighten the trigger mounting screw ① so that it is snug and the assembly does not move around on the receiver.

4. Check operation of the safety, it should engage in both positions with a definite click.

5. *Install the action in the stock.* With some actions it may be necessary to relieve the stock in certain areas. If this is necessary, we like to use a Dremel tool or you could use a file or even a chisel could be used.

Trigger Adjustments

- A. Screw ③ is the pull weight adjustment screw. Turn this screw clockwise to increase the pull weight and counter-clockwise to reduce the pull weight.
- B. Screw ② (behind the safety) is the over-travel adjustment screw and screw ④ (again behind the safety) is the sear engagement adjustment screw. *These screws are set to their optimum settings during testing at the factory, so it should not be necessary to change these settings. If you feel it is necessary to make adjustments to these please call the factory first.*

As a service to you, Timney Mfg., Inc. will install your Timney® trigger for \$25.00 plus shipping and handling.

TIMNEY® ADJUSTABLE TRIGGER GUARANTEE

Material and workmanship: This TIMNEY® trigger has been carefully designed, inspected, tested and calibrated to give a lifetime of dependable service. Every possible care has been exercised in its design and construction. If any defect in workmanship or material should develop under conditions of normal use and service, necessary repairs, including parts and labor will be made at no charge to the purchaser, providing that our inspection reveals the trigger was not damaged through accident, alteration, misuse, abuse or other cause beyond our control. We neither assume nor imply any oral or statutory warranties, and we neither assume nor authorize any person to assume us for any obligation or liability in connection with this trigger. Repairs or disassembly of this trigger in any manner without specific factory authorization voids this guarantee.

TIMNEY Mfg., Inc., 3940 W. Clarendon Ave., Phoenix, AZ 85019
602-274-2999 Fax 602-241-0361
service@timneymfg.com www.timneytriggers.com