


SKB

COMPONENTS	NUMBER		COMPONENTS	NUMBER	
	12 GAUGE	20 GAUGE		12 GAUGE	20 GAUGE
Barrel for 100	601010	301010	Selector spring plunger	609013	309013
Barrel for 200 E	601020	301020	Selector spring	609014	309014
Barrel for 300 E	601030	301030	Selector spring screw	609015	309015
Barrel for 400 E	601040	301040	Connector guide plate pin	609016	309016
Front sight	602000	302000	Connector pin washer	609017	309017
Middle band brass	603000	303000	Connector pin spring-washer	609018	309018
Top lever for 100	604010	304010	Trigger plate	609400	309400
Top lever for 200 E	604020	304020	Trigger plate screw	609401	309401
Top lever for 300 E	604030	304030	Safety button	609500	309500
Top lever for 400 E	604040	304040	Safety button pin	609501	309501
Top lever spring	604001	304001	Automatic safety lever	609700	309700
Top lever shaft	604002	304002	Automatic safety lever pin	609701	309701
Top lever retainer	604003	304003	Automatic safety connector	609702	309702
Top lever screw	604004	304004	Automatic safety connector pin	609703	309703
Locking piece for 100	605110	305110	Automatic safety connector pin snap	609704	309704
Locking piece for 200 E	605120	305120	Trigger lock	609800	309800
Locking piece for 300 E	605130	305130	Safety button spring	609801	309801
Locking piece for 400 E	605140	305140	Safety button spring retaining screw	609802	309802
Extractor	605300	305300	Trigger guard screw	610001	310001
Extractor screw	605301	305301	Trigger guard for 100	610010	310010
Extractor kicker	605302	305302	Trigger guard for 200 E	610020	310020
Extractor kicker screw	605303	305303	Trigger guard for 300 E	610030	310030
Extractor guide pin	605304	305304	Trigger guard for 400 E	610040	310040
Extractor guide pin for ejector (left & right)	605324	305324	Forend wood for 100	611010	311010
Extractor kicker for ejector	605325	305325	Forend wood for 200 E	611020	311020
Ejector extractor left	605353	305353	Beavertail forend wood for 300 E	611030	311030
Ejector extractor right	605359	305359	Beavertail forend wood for 400 E	611040	311040
Hammer left	606130	306130	Forend piece	611100	311100
Sear left	606131	306131	Forend piece screw	611101	311101
Sear spring left	606132	306132	Forend piece screw for beavertail forend	611102	311102
Sear spring screw left	606133	306133	Forend nut	611103	311103
Hammer right	606190	306190	Forend piece for ejector	611150	311150
Sear right	606191	306191	Forend locking piece	611200	311200
Sear spring right	606192	306192	Forend locking piece screw	611201	311201
Sear spring screw right	606193	306193	Forend push down rod	611202	311202
Sear pin	606300	306300	Forend push down rod guide	611203	311203
Hammer pin	606400	306400	Forend push down spring	611204	311204
Hammer spring left & right	606500	306500	Forend push down rod guide retaining screw	611205	311205
Cocking lever left	606730	306730	Forend push down rod guide ret. screw washer	611206	311206
Cocking lever for ejector left	606735	306735	Forend push down rod for B. T.	611252	311252
Cocking lever right	606790	306790	Forend push down rod guide for B. T.	611253	311253
Cocking lever for ejector right	606795	306795	Forend push down spring for B. T.	611254	311254
Cocking lever pin	606800	306800	Forend push down rod guide ret. screw for B. T.	611255	311255
Cocking lever pin stopper	606801	306801	Forend push down rod guide ret. scr. was. for B. T.	611256	311256
Cocking lever spring for ejector left & right	606900	306900	Ejector hammer left	612135	312135
Cocking lever spring screw for ejector	606901	306901	Ejector hammer right	612195	312195
Receiver for 100	608010	308010	Ejector spring for left & right	612400	312400
Receiver for 200 E	608020	308020	Ejector hammer sear pin	612500	312500
Receiver for 300 E	608030	308030	Ejector spring retainer piece	612650	312650
Receiver for 400 E	608040	308040	Stock bolt	616001	316001
Floor plate	608100	308100	Stock bolt nut	616002	316002
Floor plate screw	608101	308101	Stock bolt washer	616003	316003
Trigger assembly with selector	609000	309000	Stock bolt spring washer	616004	316004
Trigger A chrome plated	609001A	309001A	Receiver shank	616005	316005
Trigger B gold plated	609001B	309001B	Receiver tang screw	616006	316006
Trigger pin	609002	309002	Stock for 100	616010	316010
Trigger pin retaining snap	609003	309003	Stock for 200 E	616020	316020
Connector	609004	309004	Stock for 300 E	616030	316030
Connector pin	609005	309005	Stock for 400 E	616040	316040
Connector spring	609006	309006	Butt plate	616100	316100
Connector spring plunger	609007	309007	Butt plate screw	616101	316101
Connector holder (fixed)	609008	309008	Butt plate spacer	616102	316102
Trigger spring	609009	309009	Pistol grip cap	616201	316201
Trigger spring retaining screw	609010	309010	Pistol grip cap screw	616202	316202
Connector guide plate	609011	309011	Pistol grip cap spacer	616203	316203
Selector button	609012	309012	Metal plate for 200 E round	620020	320020
			Metal plate for 300 E square	620030	320030
			Metal plate for 400 E square	620040	320040