PRELIMINARY

Am486[™]SX2-50 MHz

High-Performance, Clock-Doubled, 32-Bit Microprocessor

Advanced Micro Devices

DISTINCTIVE CHARACTERISTICS

- Binary Compatible with Large Software Base
 - MS-DOS, OS/2, Windows™
 - UNIX, Windows NT ™

High Integration On-Chip

- 8-Kbyte code and data cache
- Paged, virtual memory management

Easy to Use

- Built-in self test
- Hardware debugging support
- Extensive third-party software support
- Standard 168-Pin PGA Package
- IEEE 1149.1 Boundary Scan Compatibility on all versions
- Standard DX2 Pinout

GENERAL DESCRIPTION

The Am486SX2 CPU offers the highest performance for DOS, OS/2, Windows, and UNIX applications. It is binary compatible with the 386 architecture. One million plus transistors integrate cache memory and memory management on-chip while retaining binary compatibility with previous members of the x86 architectural family. Frequently used instructions execute in one cycle, resulting in RISC performance levels. An 8-Kbyte unified code and data cache combine with an 80-Million bytes/second burst bus at 25 MHz to ensure high system throughput.

New features enhance multiprocessing systems. New instructions speed manipulation of memory-based

High-performance Design

- Frequent instructions execute in one clock
- 50-MHz clock frequency
- 80-Million bytes/second burst bus at 25 MHz
- 0.7-micron CMOS process technology
- Dynamic bus sizing for 8-, 16-, and 32-bit buses
- Complete 32-bit Architecture
 - All registers
 - 8-, 16-, and 32-bit data types
- Multiprocessor Support
 - Multiprocessor instructions
 - Cache consistency protocol
 - Support for second-level cache

semaphores. On-chip hardware ensures cache consistency and provides hooks for multilevel caches.


The Am486SX2 microprocessor features boundary scan test signals. This provides additional testability features compatible with the IEEE Standard Test Access Port and Boundary Scan Architecture (IEEE Standard 1149.1 JTAG).

The built-in self test extensively tests on-chip logic, cache memory, and the on-chip paging translation cache. Debug features include breakpoint traps on code execution and data accesses.

This document contains information on a product under development at Advanced Micro Devices, Inc. The information is intended to Publication# 17815 Rev. B Amendment /0 Issue Date: February 1994

PRELIMINARY

Am486 CPU PIPELINED 32-BIT MICROARCHITECTURE BLOCK DIAGRAM



17815B-001

Am486SX2 Microprocessor

CONNECTION DIAGRAMS Am486 CPU Pin Side View

168-Pin PGA (Pin Grid Array) Package

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	
s	A27 0	A26 0	A23 0	NC	A14 O	V _{ss}	A12 0	V _{ss}	V _{ss}	V _{ss}	V _{ss}	V _{ss}	A10 0	V _{ss}	A6 O	A4 O	ADS O	S
R	A28	A25	V _{cc}	V _{ss}	A18 O	Voc	A15 O	V _{cc}	V _{cc}	Vcc	Vcc	A11 O	А8 О	V _{cc} O	0	BLAST	0	R
Q	A31	V _{ss}	A17 0	A19	A21	A24	A22	A20	A16	A13 0	A9 O	A5 0	A7 0	A2 O	BREQ	0	0	Q
Р	0	A29	A30												HLDA O	Vcc	V _{ss}	P
N	D2 0	D1 O	DP0												O	M/10	W/R O	N
м	V _{ss}	Vcc	D4 O												D/C O	V _{cc}	V _{ss}	м
L	V _{ss}	D6 O	07												PWT	Vcc	V _{ss}	L
к	V _{ss}	V _{cc}	D14												BEO	Vcc	V _{ss}	к
J	V _{cc} O	D5	D16												BE2	BE1	PCD	J
н	V _{ss} O	D3 O	DP2 O												BRDY	Vcc	V _{ss} O	н
G	V _{ss}	V _{cc}	D12												NC	V _{cc}	V _{ss}	G
F	OP1		D15												KEN O	RDY O	BE3	F
E	V _{ss} O D9	O D13	D10 O D17												HOLD	V _{cc}	V _{ss}	E
D	O D11	O D18	O	Vcc	Vcc	D27	D26	D28	D30	NC	115	NO	NO		A20M O	BS8 O	BOFF O	D
С	O D19	O D21	O Vss	O V _{ss}	O V _{ss}	O D25	O V _{cc}	O D31	O V _{cc}	0		NC	NC	0	O NMI	O	0	c
в	0	0	O TCK	0	0	0	0	0	0	NC	0	NC	NC	O	0	0	EADS O	в
A	0	022	O	D23	DP3	D24	Vss	D29	Vss	NC	V _{ss}	NC	NC	O	NC	O	AHOLD	A
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	-

Note: NC = Not connected. To guarantee functionality with future revisions, these pins must not be connected.

Am486SX2 Microprocessor

3

17852B-002

AMD

AMD

PRELIMINARY

CONNECTION DIAGRAMS Am486 CPU Top Side View

168-Pin PGA (Pin Grid Array) Package

	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	
s	ADS	A4 O	A6 O	Vss	A10 O	V _{ss}	Vss	V _{ss}	V _{ss}	V _{ss}	A12 O	V _{ss}	A14 O	NC	A23	A26	A27 O	s
R	NC	BLAST	A3 O	Voc	A8 O	A11 O	Vcc	Voc	Voc	Voc	A15 O	Voc	A18 O	V _{ss}	Voc	A25	A28	R
Q	PCHK	PLOCK	BREQ	A2 O	A7 O	A5 O	A9 O	A13 0	A16 0	A20	A22 0	A24	A21 0	A19 0	A17 O	V _{ss}	A31 O	Q
P	V _{ss}	Vcc	HLDA			-									A30	A29		P
N	W/R O	MIO	LOCK												DP0 O	D1 O	D2 O	N
м	V _{ss}	V _{co}	D/C O												D4	V _{cc}	V _{ss}	M
L	V _{ss}	V _{co}	PWT												D7 O	D6 O	V _{ss}	L
ĸ	V _{ss}	V _{co}	BEO												D14 O	V _{cc}	V _{ss}	ĸ
J	PCD	BEI	BE2												D16	D5 O	v	J
н	V _{ss}	V _c o O	BRDY												DP2	D3	V _{ss}	
G	V _{ss}	V ₀₀ V	NC												D12	Vcc	V _{ss}	H
F	BE3	RDY	KEN												D15	O D8	DP1	
E		0 200	HOLD												O D10	0	O Vss	F
	BOFF		O A20M												O D17	O D13	D9	
D	-	-	FLUSH		NC	NC	UP	NC	D30	D28	D26	D27	Vcc	Vcc	CLK	O D18	O D11	D
C	EADS	-	O NMI	O TMS	O NC	O NC	O V _{cc}	O NC	O Vcc	O D31	O V _c o	O D25	O V _{ss}	O V _{ss}	O V _{ss}	O D21	O D19	C
в	AHOLD		O NC	O E	O NC	O NC	O V _{ss}	O NC	O Vss	O D29	O V _{SS}	O D24	O DP3	O D23	Отск	O D22	O D20	В
A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2/	A
	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	

Note: NC = Not connected. To guarantee functionality with future revisions, these pins must not be connected.

17852B-003


4

Am486SX2 CPU Pin Designations (Functional Grouping)

Add	ress	Da	ata	Con	trol	Te	est	NC	Vcc	V _{ss}
Pin Name	Pin No.	Pin Name	Pin No.	Pin Name	Pin No.	Pin Name	Pin No.	Pin No.	Pin No.	Pin No.
A2	Q14	D0	P1	A20M	D15	TCK	A3	A10	B7	A7
A3	R15	D1	N2	ADS	S17	TDI	A14	A12	B9	A9
A4	S16	D2	N1	AHOLD	A17	TDO	B16	A13	B11	A11
A5	Q12	D3	H2	BEO	K15	TMS	B14	A15	C4	B3
A6	S15	D4	MЗ	BE1	J16			B10	C5	B4
A7	Q13	D5	J2	BE2	J15			B12	E2	B5
A8	R13	D6	L2	BE3	F17			B13	E16	E1
A9	Q11	D7	L3	BLAST	R16			C10	G2	E17
A10	S13	D8	F2	BOFF	D17			C12	G16	G1
A11	R12	D9	D1	BRDY	H15			C13	H16	G17
A12	S7	D10	E3	BREQ	Q15			C14	J1	H1
A13	Q10	D11	C1	BS8	D16			G15	K2	H17
A14	S5	D12	G3	BS16	C17			R17	K16	K1
A15	R7	D13	D2	CLK	C3			S4	L16	K17
A16	Q9	D14	K3	D/C	M15				M2	L1
A17	Q3	D15	F3	DPO	N3				M16	L17
A18	R5	D16	J3	DP1	F1			1 March 1	P16	M1
A19	Q4 .	D17	D3	DP2	НЗ			198	R3	M17
A20	Q8	D18	C2	DP3	A5			Par line	R6	P17
A21	Q5	D19	B1	EADS	B17	1000			R8	Q2
A22	Q7	D20	A1	FLUSH	C15				R9	R4
A23	S3	D21	B2	HLDA	P15				R10	S6
A24	Q6	D22	A2	HOLD	E15				R11	S8
A25	R2	D23	A4	INTR	A16				R14	S9
A26	S2	D24	A6	KEN	F15					S10
A27	S1	D25	B6	LOCK	N15				1.5.6	S11
A28	R1	D26	C7	M/IO	N16					S12
A29	P2	D27	C6	NMI	B15					S14
A30	P3	D28	C8	PCD	J17	1.				
A31	Q1	D29	A8	PCHK	Q17			1000		
		· D30	C9	PWT	L15					
		D31	B8	PLOCK	Q16					
				RDY	F16					
				RESET	C16					
				UP(1)	C11				118	
				W/R	N17				1000	


Note: 1. This pin is No-Connect on the Am486SX microprocessor. For compatibility with previous designs it can still be left unconnected.

Am486SX2 Microprocessor



ORDERING INFORMATION Standard Products

AMD standard products are available in several packages and operating ranges. The order number (Valid Combination) is formed by a combination of the elements below.



TEMPERATURE RANGE Blank = Commercial ($T_{CASE} = 0^{\circ}C$ to +85°C)

SPEED OPTION -50 = 50 MHz

DEVICE NUMBER/DESCRIPTION 80486SX2 Am486SX2 High-Performance, 32-Bit Microprocessor

AMD

PACKAGE TYPE A = 168-Pin PGA (Pin Grid Array)

	Valid Combinatio	ons
A	80486SX2	-50

Valid Combinations

Valid Combinations list configurations planned to be supported in volume for this device. Consult the local AMD sales office to confirm availability of specific valid combinations and to check on newly released combinations.

Am486SX2 Microprocessor

PIN DESCRIPTIONS

The following paragraphs define the pins (signals) of the Am486SX2 microprocessor.

A31-A4/A3-2

Address Lines (Inputs/Outputs)/(Outputs)

Pins A31–A2, together with the byte enable pins $\overline{BE3}$ – $\overline{BE0}$, constitute the address bus and define the physical area of memory or input/output space accessed. Address lines A31–A4 are used to drive addresses into the microprocessor to perform cache line invalidations. Input signals must meet setup and hold times t_{22} and t_{23} . A31–A2 are not driven during bus or address hold.

A20M

Address Bit 20 Mask (Active Low; Input)

When the address mask is asserted, the Am486SX2 microprocessor masks physical address bit 20 (A20) before performing a lookup to the internal cache or driving a memory cycle on the bus. $\overline{A20M}$ emulates the address wraparound at 1 Mbyte, which occurs on the 8086. $\overline{A20M}$ is active Low and should be asserted only when the processor is in Real Mode. This pin is asynchronous but should meet setup and hold times t_{a0} and t_{a1} for recognition in any specific clock. For proper operation, $\overline{A20M}$ should be sampled High at the falling edge of RESET.

ADS

Address Status (Active Low; Output)

This pin is used to indicate that a valid bus cycle definition and address are available on the cycle definition lines and address bus. ADS is driven active in the same clock in which the addresses are driven. ADS is active Low and is not driven during bus hold.

AHOLD

Address Hold (Active High; Input)

An address hold request allows another bus master access to the Am486SX2 microprocessor's address bus for a cache invalidation cycle. The Am486SX2 microprocessor stops driving its address bus in the clock following AHOLD going active. Only the address bus is floated during address hold; the remainder of the bus remains active. AHOLD is active High and is provided with a small internal pull-down resistor. For proper operation, AHOLD must meet setup and hold times t_{18} and t_{19} .

BE3-BEO

Byte Enables (Active Low; Outputs)

The address bus byte-enable pins indicate active bytes during read and write cycles. During the first cycle of a cache fill, the external system should assume that all byte enables are active. $\overline{\text{BE3}}$ applies to D31–D24, $\overline{\text{BE2}}$ applies to D23–D16, $\overline{\text{BE1}}$ applies to D15–D8, and $\overline{\text{BE0}}$ applies to D7–D0. $\overline{\text{BE3}}$ – $\overline{\text{BE0}}$ are active Low and are not driven during bus hold.

BS8/BS16

Bus Size 8 (Active Low; Input)/ Bus Size 16 (Active Low; Input)

The bus sizing pins cause the Am486SX2 microprocessor to run multiple bus cycles to complete a request from devices that cannot provide or accept 32 bits of data in a single cycle. The bus sizing pins are sampled every clock. The state of these pins in the clock before RDY is used by the Am486SX2 microprocessor to determine the bus size. These signals are active Low and are provided with internal pull-up resistors. These inputs must satisfy setup and hold times t_{14} and t_{15} for proper operation.

BLAST

Burst Last (Active Low; Output)

This pin indicates that the next time BRDY is returned then the burst bus cycle is complete. BLAST is active for both burst and non-burst bus cycles. BLAST is active Low and is not driven during bus hold.

BOFF

Backoff (Active Low; Input)

This input pin forces the Am486SX2 microprocessor to float its bus in the next clock. The microprocessor floats all pins normally floated during bus hold, but HLDA is not asserted in response to BOFF. BOFF has higher priority than RDY or BRDY; if both are returned in the same clock, BOFF takes effect. The microprocessor remains in bus hold until BOFF is negated. If a bus cycle is restarted. BOFF is active Low and must meet setup and hold times t_{18} and t_{19} for proper operation.

BRDY

Burst Ready Input (Active Low; Input)

The BRDY signal performs the same cycle during a burst cycle that RDY performs during a non-burst cycle. BRDY indicates that the external system has presented valid data in response to a read, or that the external system has accepted data in response to write. BRDY is ignored when the bus is idle and at the end of the first clock in a bus cycle.

BRDY is sampled in the second and subsequent clocks of a burst cycle. The data presented on the data bus is strobed into the microprocessor when BRDY is sampled active. If RDY is returned simultaneously with BRDY, BRDY is ignored and the burst cycle is prematurely aborted.

 $\overline{\text{BRDY}}$ is active Low and is provided with a small pull-up resistor. $\overline{\text{BRDY}}$ must satisfy the setup and hold times t_{16} and $t_{17}.$

BREQ

Internal Cycle Pending (Output)

BREQ indicates that the Am486SX2 microprocessor has internally generated a bus request. BREQ is generated whether or not the Am486SX2 microprocessor is

driving the bus. BREQ is active High and is never floated, except during three-state test mode (see FLUSH).

CLK

Clock (Input)

The CLK input provides the fundamental timing and the internal operating frequency for the Am486SX2 microprocessor. All external timing parameters are specified with respect to the rising edge of CLK.

D31-D0

Data Lines (Inputs/Outputs)

Lines D7–D0 define the least significant byte of the bus while lines D31–D24 define the most significant byte of the data bus. These signals must meet setup and hold times t_{22} and t_{23} for proper operation on reads. These pins are driven during the second and subsequent clocks of write cycles.

D/C

Data/Control (Output)

This bus cycle definition pin distinguishes data cycles, either memory or I/O, from control cycles. These control cycles are: interrupt acknowledge, halt, and instruction fetching.

DP3-DP0

Data Parity (Inputs/Outputs)

Data parity is generated on all write data cycles with the same timing as the data driven by the Am486SX2 microprocessor. Even parity information must be driven back into the microprocessor on the data parity pins with the same timing as read information; this ensures that the correct parity check status is indicated by the Am486SX2 microprocessor. The signals read on these pins do not affect program execution.

Input signals must meet setup and hold times t_{22} and t_{23} . DP3–DP0 should be connected to V_{cc} through a pull-up resistor in systems not using parity. DP3–DP0 are active High and are driven during the second and subsequent clocks of write cycles.

EADS

Valid External Address (Active Low; Input)

This address indicates a valid external address has been driven onto the Am486SX2 microprocessor address pins. This address is used to perform an internal cache invalidation cycle. EADS is active Low and is provided with an internal pull-up resistor. EADS must satisfy setup and hold times t_{12} and t_{13} for proper operation.

FLUSH

Cache Flush (Active Low; Input)

FLUSH forces the Am486SX2 microprocessor to flush its entire internal cache. This input pin is active Low and

need only be asserted for one clock. FLUSH is asynchronous but setup and hold times t_{20} and t_{21} must be met for recognition in any specific clock. FLUSH being sampled Low in the clock before the falling edge of RESET causes the Am486SX2 microprocessor to enter the three-state test mode.

HLDA

Hold Acknowledge (Output)

The HLDA signal is activated in response to a hold request presented on the HOLD pin. HLDA indicates that the Am486SX2 microprocessor has given the bus to another local bus master. HLDA is driven active in the same clock in which the Am486SX2 microprocessor floats its bus. HLDA is driven inactive when leaving bus hold. HLDA is active High and remains driven during bus hold. HLDA is never floated except during three-state test mode (see FLUSH).

HOLD

Bus Hold Request (Input)

HOLD gives another bus master control of the Am486SX2 microprocessor bus. In response to HOLD going active, the Am486SX2 microprocessor floats most of its output and input/output pins. HLDA is asserted after completing the current bus cycle, burst cycle, or sequence of locked cycles. The Am486SX2 microprocessor remains in this state until HOLD is deasserted. HOLD is active High and is not provided with an internal pull-down resistor. HOLD must satisfy setup and hold times t_{18} and t_{19} for proper operation.

INTR

Maskable Interrupt (Input)

When asserted, this signal indicates that an external interrupt has been generated. If the internal interrupt flag is set in EFLAGS, active interrupt processing is initiated. The Am486SX2 microprocessor generates two locked interrupt acknowledge bus cycles in response to the INTR pin going active. INTR must remain active until the interrupt acknowledges have been performed to ensure that the interrupt is recognized. INTR is active High and is not provided with an internal pull-down resistor. INTR is asynchronous, but must meet setup and hold times t_{20} and t_{21} for recognition in any specific clock.

KEN

Cache Enable (Active Low; Input)

KEN is used to determine whether the current cycle is cacheable. When the Am486SX2 microprocessor generates a cacheable cycle and KEN is active one clock before $\overline{\text{RDY}}$ or $\overline{\text{BRDY}}$ during the first transfer of the cycle, the cycle becomes a cache line fill cycle. Returning KEN active one clock before $\overline{\text{RDY}}$ during the last read in the cache line fill causes the line to be placed in the on-chip cache. KEN is active Low and is provided

with a small internal pull-up resistor. $\overline{\text{KEN}}$ must satisfy setup and hold times t_{14} and t_{15} for proper operation.

LOCK

Bus Lock (Active Low; Output)

This pin indicates that the current bus cycle is locked. The Am486SX2 microprocessor does not allow a bus hold when LOCK is asserted (but address holds are allowed). LOCK goes active in the first clock of the first locked bus cycle and goes inactive after the last clock of the last locked bus cycle. The last locked cycle ends when RDY is returned. LOCK is active Low and is not driven during bus hold. Locked read cycles will not be transformed into cache fill cycles if KEN is returned active.

M/IO

Memory (Input/Output) (Output)

This bus cycle definition pin distinguishes memory cycles from input/output cycles.

NMI

Non-maskable Interrupt (Input)

The NMI request signal indicates that an external nonmaskable interrupt has been generated. NMI is rising edge sensitive. NMI must be held Low for at least four CLK periods before this rising edge. NMI is not provided with an internal pull-down resistor. NMI is asynchronous, but must meet setup and hold times t_{20} and t_{21} for recognition in any specific clock.

PCD/PWT

Page Cache Disable/Page Write-Through (Outputs)

These pins reflect the state of the page attribute bits, PWT and PCD, in the page table entry or page directory entry. If paging is disabled or for unpaged cycles, PWT and PCD reflect the state of the PWT and PCD bits in Control Register 3. PWT and PCD have the same timing as the cycle definition pins (M/\overline{IO} , D/\overline{O} , and W/\overline{R}). PWT and PCD are active High and are not driven during bus hold. PCD is masked by the Cache Disable Bit (CD) in Control Register 0.

PCHK

Parity Status (Active Low; Output)

Parity status is driven on the PCHK pin the clock after RDY for read operations. The parity status is for data sampled at the end of the previous clock. A parity error is indicated by PCHK being Low. Parity status is only checked for enabled bytes as indicated by the byte enable and bus size signals. PCHK is valid only in the clock immediately after read data is returned to the microprocessor; at all other times PCHK is inactive High. PCHK is never floated, except during three-state test mode (see FLUSH).

PLOCK

Pseudo-Lock (Active Low; Output)

PLOCK indicates that the current bus transaction requires more than one bus cycle to complete. Examples of such operations are segment table descriptor reads (64 bits) and cache line fills (128 bits). The Am486SX2 microprocessor drives PLOCK active until the addresses for the last bus cycle of the transaction have been driven, regardless of whether RDY or BRDY have been returned.

PLOCK is a function of the BS8, BS16, and KEN inputs. PLOCK should be sampled on the clock RDY is returned. PLOCK is active Low and is not driven during bus hold.

RESET

Reset (Active High; Input)

RESET forces the Am486SX2 microprocessor to begin execution at a known state. The microprocessor cannot begin execution of instructions until at least 1 ms after V_{cc} and CLK have reached their proper DC and AC specifications. The RESET pin should remain active during this time to ensure proper microprocessor operation. RESET is active High. RESET is asynchronous but must meet setup and hold times t_{20} and t_{21} for recognition in a specific clock.

RDY

Non-Burst Ready (Active Low; Input)

This pin indicates that the current bus cycle is complete. RDY indicates that the external system has presented valid data on the data pins in response to a read, or that the external system has accepted data from the Am486SX2 microprocessor in response to a write. RDY is ignored when the bus is idle and at the end of the bus cycle's first clock.

RDY is active during address hold. Data can be returned to the processor while AHOLD is active.

 $\overline{\text{RDY}}$ is active Low and is not provided with an internal pull-up resistor. $\overline{\text{RDY}}$ must satisfy setup and hold times t_{16} and t_{17} for proper chip operation.

TCK

Test Clock (Input)

Test Clock is an input to the Am486 CPU and provides the clocking function required by the JTAG boundary scan feature. TCK is used to clock state information and data into and out of the component. State select information and data are clocked into the component on the rising edge of TCK on TMS and TDI, respectively. Data is clocked out of the component on the falling edge of TCK on TDO.



TDI

Test Data Input (Input)

TDI is the serial input used to shift JTAG instructions and data into the component. TDI is sampled on the rising edge of TCK during the SHIFT-IR and the SHIFT-DR TAP (Tap Access Port) controller states. During all other TAP controller states, TDI is a "don't care."

TDO

Test Data Output (Output)

TDO is the serial output used to shift JTAG instructions and data out of the component. TDO is driven on the falling edge of TCK during the SHIFT-IR and SHIFT-DR TAP controller states. At all other times, TDO is driven to the high impedance state.

TMS

Test Mode Select (Input)

TMS is decoded by the JTAG TAP to select the operation of the test logic. TMS is sampled on the rising edge of TCK. To guarantee deterministic behavior of the TAP controller, TMS is provided with an internal pull-up resistor.

W/R

Write/Read (Output)

A bus cycle definition pin, W/\overline{R} distinguishes write cycles from read cycles.

UP

Upgrade Present (Input)

The Upgrade Present pin forces the Am486SX2 CPU to three-state all its outputs and enter the power-down mode. When the Upgrade Present pin is sampled asserted by the CPU in the clock before the falling edge of RESET, the power-down mode is enabled. UP has no effect on the power-down status except during this edge. The CPU is also forced to three-state all of its outputs immediately in response to this signal. The UP signal must remain asserted in order to keep the pins three-stated. UP is active Low and is provided with an internal pull-up resistor.

Table 1. Output Pins

Name	Active Level	Floated At
BREQ	High	
HLDA	High	
BE3-BE0	Low	Bus Hold
PCD/PWT	High	Bus Hold
W/R, D/C, M/IO	High	Bus Hold
LOCK	Low	Bus Hold
PLOCK	Low	Bus Hold
ADS	Low	Bus Hold
BLAST	Low	Bus Hold
PCHK	Low	
A3-A2	High	Bus, Address Hold

Name	Active Level	Synchronous/ Asynchronous
CLK		
RESET	High	Asynchronous
HOLD	High	Synchronous
AHOLD	High	Synchronous
EADS	Low	Synchronous
BOFF	Low	Synchronous
FLUSH	Low	Asynchronous
A20M	Low	Asynchronous
BS16 , BS8	Low	Synchronous
KEN	Low	Synchronous
RDY	Low	Synchronous
BRDY	Low	Synchronous
INTR	High	Asynchronous
NMI	High	Asynchronous
UP	Low	Asynchronous

Table 3. Input/Output Pins

Name	Active Level	Floated At
D31-D0	High	Bus Hold
DP3–DP0 A31–A4	High High	Bus Hold Bus, Address Hold

Table 4. Bus Cycle Definition

M/IO	D/C	W/R	Bus Cycle Initiated
0	0	0	Interrupt Acknowledge
0	0	1	Halt/Special Cycle
0	1	0	I/O Read
0	1 1	1	I/O Write
1	0	0	Code Read
1	0	1	Reserved
1	1 1	0	Memory Read
1	1 1	1	Memory Write

Table 5. Test Pins

Name	Input or Output	Sampled/Driven On
TCK	Input	N/A
TDI	Input	Rising Edge of TCK
TDO	Output	Falling Edge of TCK
TMS	Input	Rising Edge of TCK

Am486SX2 Microprocessor

CPU IDENTIFICATION CODES

The DX register always contains a component identification at the conclusion of RESET. The upper byte of DX (DH) will contain 04 and the lower byte of DX (DL) will contain a CPU type/stepping identifier.

(DH)	Component ID (DL)
------	----------------------

Table 6. CPU ID

Table 7. JTAG ID Code

Version Code	Part Number Code	Manufacturer Identity
00h	0422	01

ARCHITECTURAL OVERVIEW

The Am486SX2 microprocessor is a 32-bit architecture with on-chip memory management and cache memory units. It is a fully compatible member of the Am486 family.

The Am486SX2 microprocessor contains all the features of the 386 microprocessor with enhancements to increase performance. The instruction set includes the complete 386 microprocessor instruction set along with extensions to serve new applications. The on-chip Memory Management Unit (MMU) is completely compatible with the 386 MMU. All software written for the 386 microprocessor and previous members of the x86 architectural family can run on the Am486SX2 microprocessor without any modifications.

Several enhancements have been added to the Am486SX2 microprocessor to increase performance. On-chip cache memory allows frequently used data and code to be stored on-chip, thereby reducing accesses to the external bus. RISC design techniques have been used to reduce instruction cycle times. A burst bus feature enables fast cache fills. All of these features combined lead to performance greater than twice that of a 386 microprocessor.

The Am486 microprocessor MMU consists of a segmentation unit and a paging unit. Segmentation allows management of the logical address space by providing easy data and code relocatibility and efficient sharing of global resources. The paging mechanism operates beneath segmentation and is transparent to the segmentation process. Paging is optional and can be disabled by system software. Each segment can be divided into one or more 4-Kbyte segments. To implement a virtual memory system, the Am486SX2 microprocessor supports full restartability for all page and segment faults.

12

Memory is organized into one or more variable length segments, each up to 4 Gbyte (2³² bytes) in size. A segment can have attributes associated with it. These attributes include its location, size, type (i.e., stack, code, or data), and protection characteristics. Each task on an Am486SX2 microprocessor can have a maximum of 16,381 segments, each up to 4 Gbyte in size. Thus, each task has a maximum of 64 Tbyte (terabytes) of virtual memory.

The segmentation unit provides four levels of protection for isolating and protecting applications and the operating system from each other. The hardware enforced protection allows high integrity system designs.

The Am486SX2 microprocessor has two modes of operation: Real Address Mode (Real Mode) and Virtual Address Mode (Protected Mode). In Real Mode, the Am486SX2 microprocessor operates as a very fast 8086. Real Mode is required primarily to set up the processor for Protected Mode operation. Protected Mode provides access to the sophisticated memory management paging and privilege capabilities of the processor.

Within Protected Mode, software can perform a task switch to enter into tasks designated as Virtual 8086 Mode tasks. Each Virtual 8086 task behaves with 8086 semantics, allowing 8086 software (an application program or an entire operating system) to execute.

The on-chip cache is 8 Kbyte. It is four-way set associative and follows a write-through policy. The on-chip cache includes features that provide flexibility in external memory system design. Individual pages can be designated as cacheable or non-cacheable by software or hardware. The cache can also be enabled and disabled by software or hardware.

Finally, the Am486SX2 microprocessor has features that facilitate high-performance hardware designs. The 2X clock doubler improves execution performance without increasing the board design complexity. This 2X clock doubler enhances all operations operating out of the cache and/or not blocked by external bus assesses. The burst bus feature enables fast cache fills.

ELECTRICAL DATA

The following sections describe recommended electrical connections for the Am486SX2 microprocessor and its electrical specifications.

Power and Grounding

Power Connections

The Am486SX2 microprocessor is implemented in CS14 technology and has modest power requirements. However, its high clock frequency output buffers can cause power surges as multiple output buffers drive new signal levels simultaneously. For clean, on-chip power distribution at high frequency, 24 V_{cc} and 28 V_{ss} pins feed the Am486SX2 microprocessor.

Power and ground connections must be made to all external V_{cc} and GND pins of the Am486SX2 microprocessor. On the circuit board, all V_{cc} pins must be connected on a V_{cc} plane. All V_{ss} pins must likewise be connected on a GND plane.

Power Decoupling Recommendations

Liberal decoupling capacitance should be placed near the Am486SX2 microprocessor. The Am486SX2 microprocessor, driving its 32-bit parallel address and data buses at high frequencies, can cause transient power surges, particularly when driving large capacitive loads.

Low inductance capacitors and interconnects are recommended for best high-frequency electrical performance. Inductance can be reduced by shortening circuit board traces between the Am486SX2 microprocessor, and decoupling capacitors as much as possible. Capacitors specifically for PGA packages are also commercially available.

Other Connection Recommendations

NC pins should always remain unconnected.

For reliable operation, always connect unused inputs to an appropriate signal level. Active Low inputs should be connected to V_{cc} through a pull-up resistor. Pull-ups in the range of 20 K Ω are recommended. Active High inputs should be connected to GND.

AMD

ABSOLUTE MAXIMUM RATINGS

Case Temperature under Bias65°C to +110°C
Storage Temperature65°C to +150°C
Voltage on any pin
with respect to ground0.5 V to Vcc +0.5 V
Supply voltage with

 $\begin{array}{l} \mbox{respect to V_{ss}} & -0.5 \mbox{ V to } +6.5 \mbox{ V} \\ \mbox{Stresses above those listed under Absolute Maximum Ratings} \\ \mbox{may cause permanent device failure. Functionality at or above} \end{array}$

OPERATING RANGES

Commercial (C) Devices

 $\begin{array}{cccc} T_{cASE} & \dots & -0^{\circ}C \ to \ +85^{\circ}C \\ V_{cc} & \dots & 5 \ V \ \pm5\% \end{array}$

Operating ranges define those limits between which the functionality of the device is guaranteed.

may cause permanent device failure. Functionality at or above these limits is not implied. Exposure to Absolute Maximum Ratings for extended periods may affect device reliability.

DC CHARACTERISTICS over COMMERCIAL operating ranges

Symbol	Parameter	Min	Max	Unit	Notes
VIL	Input Low Voltage	-0.3	+0.8	٧	
VIH	Input High Voltage	2.0	V _{CC} + 0.3	٧	A THE REAL OF
VoL	Output Low Voltage		0.45	٧	Note 1
V _{OH}	Output High Voltage	2.4		٧	Note 2
lcc	Power Supply Current-(50 MHz)		900	mA	Note 3
ICCF	Power Supply Current in Power Down Mode	1.11.12.23	50	mA	Note 8
ILI	Input Leakage Current		+ 15	μA	Note 4
IIH	Input Leakage Current		200	μA	Note 5
IIL	Input Leakage Current		-400	μA	Note 6
ILO	Output Leakage Current		±15	μA	
CIN	Input Capacitance		13	pF	F _c = 1 MHz (Note 7)
Co	I/O or Output Capacitance-(50 MHz)		17	pF	F _c = 1 MHz (Note 7)
CCLK	CLK Capacitance		15	pF	F _c = 1 MHz (Note 7)

Notes:

- 1. This parameter is measured at: Address, Data, BEn 4.0 mA Definition, Control 5.0 mA
- 2. This parameter is measured at: Address, Data, BEn -1.0 mA Definition, Control -0.9 mA
- 3. Typical supply current
- 775 mA @ 50 MHz
- 4. This parameter is for inputs without internal pull-ups or pull-downs and $0 \le V_{IN} \le V_{CC}$.
- 5. This parameter is for inputs with internal pull-downs and $V_{IH} = 2.4 V$.
- 6. This parameter is for inputs with internal pull-ups and $V_{IL} = 0.45 V$.
- 7. Not 100% tested.
- 8. The I_{CCF} specification in the above table is a target value. It has not been tested.

SWITCHING CHARACTERISTICS over COMMERCIAL operating ranges

The AC specifications, provided in the AC characteristics table, consist of output delays, input setup requirements, and input hold requirements. All AC specifications are relative to the rising edge of the CLK signal.

AC specifications measurement is defined by Figure 3. All timings are referenced to 1.5 V unless otherwise specified. Inputs must be driven to the voltage levels indicated by Figure 2 when AC specifications are measured. Am486SX2 microprocessor output delays are specified with minimum and maximum limits. The minimum Am486SX2 microprocessor delay times are hold times provided to external circuitry. Am486SX2 microprocessor input setup and hold times are specified as minimums, defining the smallest acceptable sampling window. Within the sampling window, a synchronous input signal must be stable for correct Am486SX2 microprocessor operation.

SWITCHING CHARACTERISTICS at 50 MHz

 V_{cc} = 5 V ±5%; T_{case} = 0°C to +85°; C_{L} = 50 pF unless otherwise specified.

Symbol	Parameter	Min	Max	Unit	Figure	Notes
	Frequency	8	25	MHz		1X Clock Driven to Am486 CPU
t ₁	CLK Period		125	ns	Figure 1	
t _{1a}	CLK Period Stability		0.1%	Δ		Adjacent Clocks
t ₂	CLK High Time	14		ns	Figure 1	at 2 V
t ₃	CLK Low Time	14		ns	Figure 1	at 0.8 V
t ₄	CLK Fall Time		4	ns	Figure 1	2 V to 0.8 V
t ₅	CLK Rise Time		4	ns	Figure 1	0.8 V to 2 V
t ₆	A31–A2, PWT, PCD, BE3–BE0, M/IO, D/C, W/R, ADS, LOCK, BREQ, HLDA Valid Delay	3	19	ns	Figure 5	
t ₇	A31–A2, PWT, PCD, BE3–BE0, M/IO, D/C, W/R, ADS, LOCK Float Delay		28	ns	Figure 6	Note 1
t ₈	PCHK Valid Delay	3	24	ns	Figure 4	
t _{8a}	BLAST, PLOCK Valid Delay	3	24	ns	Figure 5	
t ₉	BLAST, PLOCK Float Delay		28	ns	Figure 6	Note 1
t ₁₀	D31-D0, DP3-DP0 Write Data Valid Delay	3	20	ns	Figure 5	
t ₁₁	D31-D0, DP3-DP0 Write Data Float Delay		28	ns	Figure 6	Note 1
t ₁₂	EADS Setup Time	8		ns	Figure 2	
t ₁₃	EADS Hold Time	3		ns	Figure 2	
t ₁₄	KEN, BS16, BS8 Setup Time	8		ns	Figure 2	
t ₁₅	KEN, BS16, BS8 Hold Time	3		ns	Figure 2	
t ₁₆	RDY, BRDY Setup Time	8		ns	Figure 3	
t ₁₇	RDY, BRDY Hold Time	3		ns	Figure 3	
t ₁₈	HOLD, AHOLD Setup Time	8		ns	Figure 2	
t _{18a}	BOFF Setup Time	8		ns	Figure 2	
t ₁₉	HOLD, AHOLD, BOFF Hold Time	3		ns	Figure 2	
t ₂₀	RESET, FLUSH, A20M, NMI, INTR Setup Time	8		ns	Figure 2	
t ₂₁	RESET, FLUSH, A20M, NMI, INTR Hold Time	3		ns	Figure 2	
t ₂₂	D31–D0, DP3–DP0, A31–A4 Read Setup Time	5		ns	Figure 2, Figure 3	
t ₂₃	D31–D0, DP3–DP0, A31–A4 Read Setup Time	3		ns	Figure 2, Figure 3	

Note:

1. Not 100% tested. Guaranteed by design characterization.



Am486SX2 Microprocessor AC Characteristics for Boundary Scan Test Signals at 25 MHz


 $V_{cc} = 5 \text{ V} \pm 5\%$; $T_{case} = 0^{\circ}\text{C}$ to $+85^{\circ}\text{C}$; $C_{L} = 0 \text{ pF}$. All inputs and outputs are TTL Level.

Symbol	Parameter	Min	Max	Unit	Figure	Notes
t ₂₄	TCK Frequency	18 .	25	MHz		1X Clock
t ₂₅	TCK Period	40		ns		Note 2
t ₂₆	TCK High Time	10		ns		at 2.0 V
t ₂₇	TCK Low Time	10		ns		at 0.8 V
t ₂₈	TCK Rise Time		4	ns		Note 1
t ₂₉	TCK Fall Time		4	ns		Note 1
t ₃₀	TDI, TMS Setup Time	8		ns	Figure 7	Note 3
t ₃₁	TDI, TMS Hold Time	7		ns	Figure 7	Note 3
t ₃₂	TDO Valid Delay	3	25	ns	Figure 7	Note 3
t ₃₃	TDO Float Delay	1000	36	ns	Figure 7	Note 3
t ₃₄	All Outputs (Non-Test) Valid Delay	3	25	ns	Figure 7	Note 3
t ₃₅	All Outputs (Non-Test) Float Delay		36	ns	Figure 7	Note 3
t ₃₆	All Inputs (Non-Test) Setup Time	8		ns	Figure 7	Note 3
t ₃₇	All Inputs (Non-Test) Hold Time	7		ns	Figure 7	Note 3


Notes: 1. Rise/Fall times are measured between 0.8 V and 2.0 V. Rise/Fall times can be relaxed by 1 ns per 10-ns increase in TCK period.


2. TCK period \geq CLK period.


3. Parameter measured from TCK.



Am486SX2 Microprocessor











PHYSICAL DIMENSIONS

For reference only. All dimensions are measured in inches. BSC is an ANSI standard for Basic Space Centering.



Bottom View (Pins Facing Up)



Side View

16734C 5/11/93 MH

Am486SX2 Microprocessor

where:

Package Thermal Specifications

The Am486SX2 microprocessor is specified for operation when T_c (the case temperature) is within the range of 0°C to +85°C. Tc can be measured in any environment to determine whether the Am486SX2 microprocessor is within specified operating range. The case temperature should be measured at the center of the top surface opposite the pins.

The ambient temperature (T_A) is guaranteed as long as T_c is not violated. The ambient temperature can be calculated from θ_{JC} and θ_{JA} and from the following equations:

 $T_{\rm J} = T_{\rm C} + P \bullet \theta_{\rm JC}$

- $T_A = T_J P \bullet \theta_{JA}$
- $T_{c} = T_{A} + P \bullet [\theta_{JA} \theta_{Jc}]$

T_J, T_A, T_c = Junction, Ambient, and Case Temperature.

 θ_{JC} , θ_{JA} = Junction-to-Case and Junction-to-Ambient Thermal Resistance, respectively.

P = Maximum Power Consumption

The values for θ_{JA} and θ_{JC} are given in Table 8 for the 1.75 sq. in., 168-pin, ceramic PGA.

Table 9 shows the T_A allowable (without exceeding Tc) at various airflows and operating frequencies (fclk). Note that T_A is greatly improved by attaching "fins" or a "heat sink" to the package. Heat sink dimensions are shown in Figure 8. P (the maximum power consumption) is calculated by using the maximum 1cc at 5 V as tabulated in the DC Characteristics.

Table 8.	Thermal Resist	ance (°C/W) θ_{Jc} and θ_{Jc}	A for the 50-MHz	Am486SX2 CPU
----------	-----------------------	---	------------------	--------------

		θ _{JA} V	s. Airflow-ft/n	nin. (m/sec)			
2	θ」ς	0 (0)	200 (1.01)	400 (2.03)	600 (3.04)	800 (4.06)	1000 (5.07)
Without Heat Sink	1.5	16.5	14.0	12.0	10.5	9.5	9.0
With Heat Sink*	2.0	12.0	7.0	5.0	4.0	3.5	3.25

*0.350" high unidirectional heat sink (Al alloy 6063-T5, 40 mil fin width, 155 mil center-to-center fin spacing).




Figure 8. Heat Sink Dimensions

17852B-113

Table 9. Maximum T_A at Various Airflows in °C


			Airflow-ft/min.	(m/sec)			
	f _{CLK} (MHz)	0 (0)	200 (1.01)	400 (2.03)	500 (3.04)	800 (4.06)	1000 (5.07)
T _A with Heat Sink	50	35	60	70	75	77.5	78.75
T _A without Heat Sink	50	10	22.5	32.5	40	45	47.5

AMD and Am386 are registered trademarks of Advanced Micro Devices, Inc. Am486 is a trademark of Advanced Micro Devices, Inc.

Windows and Windows NT are trademarks of Microsoft Corp.

Product names used in this publication are for identification purposes only and may be trademarks of their respective companies.

22



North American ALABAMA (205) 882-9122 ARIZONA (602) 242-4400 Culver City (310) 645-1524 Newport Beach (714) 752-6262 Sacramento(Roseville) (916) 786-6700 San Digo (619) 560-7030 San Jose (408) 922-0500 Woodland Hills (818) 878-9988 CANADA, Ontario, (Kanata Kanata (613) 592-0060 Willowdale (416) 222-7800 Col.ORADO (303) 741-2900 CONNECTICUT (203) 264-7800 FLORIDA, (407) 382-0292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS (708) 773-4422 Chicago (Itasca) (708) 773-4422 MASSACHUSETTS (617) 273-3970 MASSACHUSETTS (617) 273-3970 MASSACHUSETTS (617) 273-3970 NEW YORK, (614) 298-6020 Parsippany (201) 299-0002 NEW YORK, (614) 291-6350 Brewster (914) 279-8323	North Amorica	
ARIZONA (602) 242-4400 CALIFORNIA, (310) 645-1524 Newport Beach (714) 752-6262 Sacramento(Roseville) (916) 766-6700 San Diego (619) 560-7030 San Jose (408) 922-0500 Woodland Hills (818) 878-9988 CANADA, Ontario, (818) 878-9988 Kanata (613) 592-0060 Willowdale (416) 222-7800 COLORADO (303) 741-2900 COLORADO (303) 741-2900 COLORADO (303) 741-2900 Colarwater (813) 530-9971 Boca Raton (404) 449-7920 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 DAHO (208) 377-0393 ILLINOIS, (818) 730-9971 MARYLAND (301) 381-3700 MASSACHUSETTS (617) 273-3970 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW YLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (617) 273-3970 MASSACHUSETTS (617) 273-3970 <		
CALIFORNIA, (310) 645-1524 Culver City (310) 645-1524 Newport Beach (714) 752-6262 Sacaramento(Roseville) (916) 766-6700 San Jose (408) 922-0500 Woodland Hills (818) 878-9986 CANADA, Ontario, (818) 878-9986 Kanata (613) 592-0060 Willowdale (416) 222-7800 COLORADO (303) 741-2900 CONNECTICUT (203) 264-7800 FLORIDA, (161) 502-0929 GEORGIA (404) 449-7920 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (708) 773-4422 Naperville (708) 505-9617 MARYLAND (301) 381-3790 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0010 New JERSEY, (614) 931-6455 Cherry Hill (609) 662-2900 New YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 <	ARIZONA	(602) 242-4400
Culver City (310) 645-1524 Newport Beach (714) 752-6282 Sacramento(Roseville) (916) 766-6700 San Diego (619) 560-7030 San Jose (408) 922-0500 Woodland Hills (818) 878-9988 CANADA, Ontario, (818) 878-9988 Kanata (613) 592-0060 Willowdale (416) 222-7800 COLORADO (303) 741-2900 COLORADO (303) 741-2900 COLORADA (407) 861-0050 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 Chicago (Itasca) (708) 773-4422 MaryLAND (301) 381-3790 MARYLAND (301) 381-3790 MARYLAND (301) 381-3790 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MARYLAND (301) 381-3790 MINNESOTA (612) 938-0001 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050	CALIFORNIA	
Newport Beach (714) 752-6262 Sacramento(Roseville) (916) 766-6700 San Jose (408) 922-0500 Woodland Hills (818) 878-9988 CANADA, Ontario, (818) 878-9988 CANADA, Ontario, (813) 592-0060 Willowdale (416) 222-7800 COLORADO (303) 741-2900 CONRECTICUT (203) 264-7800 FLORIDA, (407) 361-0050 Clearwater (813) 530-9971 Boca Raton (407) 361-0050 Orlando (Longwood) (407) 362-9292 GEORGIA (404) 449-7920 ILLINOIS, (708) 773-4422 Chicago (Itasca) (708) 773-4422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0002 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA	Culver City	(310) 645-1524
San Diego (619) 560-703C San Jose (408) 922-050C Woodland Hills (818) 878-9986 CANADA, Ontario, (818) 878-9986 Kanata (613) 592-0060 Willowdale (416) 222-7800 COLORADO (303) 741-2900 CONNECTICUT (203) 264-7800 FLORIDA, (203) 264-7800 Clearwater (813) 530-9971 Boca Raton (407) 361-0050 Orlando (Longwood) (407) 862-9202 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 LLLINOIS, (505-9517 Chicago (Itasca) (708) 773-4422 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Calumbus (Westerville) (614) 891-64	Newport Beach	(714) 752-6262
San Diego (619) 560-703C San Jose (408) 922-050C Woodland Hills (818) 878-9986 CANADA, Ontario, (818) 878-9986 Kanata (613) 592-0060 Willowdale (416) 222-7800 COLORADO (303) 741-2900 CONNECTICUT (203) 264-7800 FLORIDA, (203) 264-7800 Clearwater (813) 530-9971 Boca Raton (407) 361-0050 Orlando (Longwood) (407) 862-9202 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 LLLINOIS, (505-9517 Chicago (Itasca) (708) 773-4422 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Calumbus (Westerville) (614) 891-64	Sacramento(Bosevil	(916) 786-6700
San José (408) 922-0500 Woodland Hills (818) 878-9986 CANADA, Ontario, (818) 878-9986 CANADA, Ontario, (818) 878-9986 Kanata (613) 592-0060 Willowdale (416) 222-7800 COLORADO (303) 741-2900 CONNECTICUT (203) 264-7800 FLORIDA, (203) 264-7800 Clearwater (813) 530-9971 Boca Raton (407) 361-0050 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (208) 377-3422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 NEW JERSEY, (612) 938-0001 NARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 NARTAROLINA (614) 891-6455 Charotte (716) 425-8050 NORTH CAROLINA (503) 245	San Diego	(619) 560-7030
CANADA, Ontario, (613) 592-0060 Willowdale (416) 222-7800 COLORADO (303) 741-2900 CONNECTICUT (203) 264-7800 FLORIDA, (203) 264-7800 Clearwater (813) 530-9971 Boca Raton (407) 361-0050 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (208) 377-0393 Chicago (Itasca) (708) 773-4422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW VORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0800 TEXAS, (215) 398-8006 <t< td=""><td>San Jose</td><td>(408) 922.0500</td></t<>	San Jose	(408) 922.0500
CANADA, Ontario, (613) 592-0060 Willowdale (416) 222-7800 COLORADO (303) 741-2900 CONNECTICUT (203) 264-7800 FLORIDA, (203) 264-7800 Clearwater (813) 530-9971 Boca Raton (407) 361-0050 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (208) 377-0393 Chicago (Itasca) (708) 773-4422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW VORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0800 TEXAS, (215) 398-8006 <t< td=""><td>Woodland Hills</td><td>(818) 878-9988</td></t<>	Woodland Hills	(818) 878-9988
Willowdale (416) 222-7800 COLORADO (303) 741-2900 CONRECTICUT (203) 264-7800 FLORIDA, (203) 264-7800 Clearwater (813) 530-9971 Boca Raton (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (708) 773-4422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MARYLAND (301) 381-3790 MARYLAND (301) 381-3790 MINNESOTA (612) 938-0001 NEW JERSEY, (617) 273-3970 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA Charlotte Columbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (513	CANADA, Ontario,	
COLORADO (303) 741-2900 CONNECTICUT (203) 264-7800 FLORIDA, (203) 264-7800 Clearwater (813) 530-9971 Boca Raton (407) 861-0050 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (208) 377-0393 ILLINOIS, (612) 938-0001 MASSACHUSETTS (612) 938-0001 NASSACHUSETTS (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, Brewster Browster (716) 425-8050 NORTH CAROLINA (716) 425-8050 NORTH CAROLINA (716) 497-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (33) 248 464 2 FRANCE, Paris TEL (03) 248 464 2 FRANCE, Paris	Kanata	
CONNECTICUT (203) 264-7800 FLORIDA, (813) 530-9971 Boca Raton (407) 361-0050 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (708) 773-4422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (716) 425-8050 NORTH CAROLINA (748) 875-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International E BeLGUIM, Antwerpen TEL (03) 248 43 00	Willowdale	
CONNECTICUT (203) 264-7800 FLORIDA, (813) 530-9971 Boca Raton (407) 361-0050 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (708) 773-4422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (716) 425-8050 NORTH CAROLINA (748) 875-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International E BeLGUIM, Antwerpen TEL (03) 248 43 00	COLORADO	
Clearwater (813) 530-9971 Boca Raton (407) 361-0050 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (208) 377-3422 Naperville (708) 505-9517 MARSACHUSETTS (617) 273-3970 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, (914) 279-8323 Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (716) 425-8050 NORTH CAROLINA (716) 425-8050 Columbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (512) 346-7830 PENNSYLVANIA (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International	CONNECTICUT	
Boca Haton (407) 361-0050 Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (208) 377-34422 Naperville (708) 505-9517 MARSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 MASSACHUSETTS (617) 273-3970 MINNESOTA (609) 662-2900 NEW JERSEY, (609) 662-2900 Cherry Hill (609) 662-2900 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (716) 425-8050 NORTH CAROLINA (716) 425-8050 Columbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-080 PENNSYLVANIA (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International		(812) 520 0071
Orlando (Longwood) (407) 862-9292 GEORGIA (404) 449-7920 IDAHO (208) 377-0393 ILLINOIS, (708) 773-4422 Chicago (Itasca) (708) 505-9517 MARYLAND (301) 381-3790 MASSACHUSETTS (612) 938-0001 NEW JERSEY, (612) 938-0001 NEW JERSEY, (201) 299-0002 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYL VANIA (215) 398-8006 TEXAS, (512) 346-7830 Dallas (214) 934-9039 Houston (713) 376-8084 International FAX BELGIUM, Antwerpen TEL (03) 248 46 42 FRANCE, Paris TEL (03) 248 46 42 FRANCE, Paris TEL (039) 406490 HOUSTON FAX (039) 248 66 42	Boca Daton	(407) 201 205
GEORGIA	Orlando (Longwood)	(407) 361-0050
IDAHO (208) 377-0393 ILLINOIS, (706) 773-4422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 NEW JERSEY, (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (716) 425-8050 Columbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 TEXAS, (214) 934-9029 Houston (713) 376-8084 International	Chando (Longwood)	(407) 862-9292
ILLINOIS, (708) 773-4422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MARYLAND (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (Alt 891-6455 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0800 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International		
Chicago (Itasca) (708) 773-4422 Naperville (708) 505-9517 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, (914) 279-8323 Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYL VANIA (215) 398-8006 TEXAS, (215) 398-8006 TEXAS, (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International (713) 376-8084 International (11 49-75-10-10 BELGIUM, Antwerpen TEL (03) 248 46 42 FRANCE, Paris TEL (06172)-24061 FAX (033) 248 06490 (06172)-24061 München TEL (06172)-24061	IDAHO	
Naperville (706) 505-9517 MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, (914) 279-8323 Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7830 Dallas (214) 934-9029 Houston (713) 376-8084 International (03) 248 46 42 FRANCE, Paris TEL (03) 248 46 42 FRANCE, Paris TEL (03) 248 46 42 FRANCE, Paris TEL (049) 406490 FAX (039) 248 66 42 571-010 GERMANY, Bad Homburg		(700) 779 4400
MARYLAND (301) 381-3790 MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, (201) 299-0002 NEW YORK, (201) 299-0002 NEW YORK, (914) 279-8323 Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (716) 425-8050 Columbus (Westerville) (614) 891-6455 Dayton (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International (32) 248 43 00 Dallas (214) 934-9099 Houston FAX Manchen TEL (03) 248 43 00 (33) 248 43 00 GERMANY, FAX Bad Homburg TEL München TEL (06172)-24061 FAX München TEL	Naperville	(708) 505 0517
MASSACHUSETTS (617) 273-3970 MINNESOTA (612) 938-0001 NEW JERSEY, (612) 938-0001 Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, Brewster Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (74) 875-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 446-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International	MARYLAND	(201) 201-9517
MINNESOTA (612) 938-0001 NEW JERSEY, (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, (914) 279-8323 Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Charlotte (704) 875-3091 Raleigh (914) 299-6022 NORTH CAROLINA (704) 875-3091 Calumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International (713) 376-8084 International FAX BELGIUM, Antwerpen TEL Machaney, FAX Bat Homburg TEL München TEL	MASSACHUSETTS	
NEW JERSEY, (609) 662-2900 Parsippany. (201) 299-0002 NEW YORK, (201) 299-0002 Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (716) 425-8050 Charlotte (704) 875-3091 Raleigh (919) 876-8111 OHIO, (614) 891-6455 Dayton (513) 439-0268 OREGON (513) 439-0268 OREGON (512) 346-7830 PENNSYLVANIA (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International (03) 248 43 00 BALGIUM, Antwerpen TEL Markine (1) 49-75-10-13 GERMANY, FAX (03) 248 44 02 FAX (03) 248 4503- München TEL (06172)-24061 Kax (06172)-24061 FAX München FAX (089) 406490 HONG KONG, TEL (02) 38103458 JAPAN, FAX (02) 38103458 JAPAN, FAX (02) 38103458	MINNESOTA	(612) 020 0001
Cherry Hill (609) 662-2900 Parsippany (201) 299-0002 NEW YORK, (201) 299-0002 Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Charlotte (704) 875-3091 Raleigh (919) 878-8111 OHIO, (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0800 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International	NEW JEBSEY	
Parsippany. (201) 299-0002 NEW YORK, 914) 279-8323 Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Charlotte (704) 875-3091 Raleigh (919) 878-8111 OHIO, (919) 878-8111 OColumbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYL VANIA (215) 398-8006 TEXAS, (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International		(600) 662 2000
NEW YORK, (914) 279-8323 Brewster (716) 425-8050 NORTH CAROLINA (716) 425-8050 Charlotte (704) 875-3091 Raleigh (919) 878-8111 OHIO, (919) 878-8111 OHIO, (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International (03) 248 43 00 BELGIUM, Antwerpen TEL Muston FAX (03) 248 43 00 FRANCE, Paris TEL (03) 248 43 00 FRANCE, Paris TEL (03) 248 44 20 FRANCE, Paris TEL (03) 248 45 03 GERMANY, FAX (04) 49-75-10-13 GERMANY, FAX (06) 221-24061 München TEL (06172)-24061 FAX (02) 3390541 FAX HAX (02) 3390541 FAX München FAX (02) 33103458 JAPAN, FAX (02) 33103458	Parsinnany	(201) 200 0002
Brewster (914) 279-8323 Rochester (716) 425-8050 NORTH CAROLINA (716) 425-8050 Charlotte (704) 875-3091 Raleigh (919) 878-8111 OHIO, (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 TEXAS, (214) 934-9099 Houston (713) 376-8084 International		
Hocnester (716) 425-8050 NORTH CAROLINA (704) 875-3091 Charlotte (919) 878-8111 OHIO, (614) 891-6455 Dayton (513) 439-0268 OREGON (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 394-67830 Dauston (214) 934-9099 Houston (713) 376-8084 International (713) 376-8084 BELGIUM, Antwerpen TEL BELGIUM, Antwerpen TEL Marker (71) 49-75-10-10 GERMANY, FAX Bad Homburg TEL München TEL München TEL Münchai FAX Münchai FAX Max (852) 865-4335 TALY, Milano TEL Mark (62) 29-8460 FAX (0462) 29-8468 Kanagawa TEL Mark (22) 28-8469 FAX (0462) 47-211 Tokyo TEL Gologa 3342-5196 <td>Browstor,</td> <td></td>	Browstor,	
NORTH CAROLINA (704) 875-3091 Raleigh (919) 878-8111 OHIO, (919) 878-8111 OHIO, (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International	Brewster	
Charlotte (704) 875-3091 Raleigh (919) 878-8111 OHIO, (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International (713) 376-8084 BELGIUM, Antwerpen TEL (03) 248 46 42 FRANCE, Paris TEL (1) 49-75-10-10 GERMANY, FAX (06172)-24061 München TEL (063) 406490 HONG KONG, FAX (089) 406490 HONG KONG, FAX (082) 865-4335 ITALY, Milano TEL (02) 3390541 JAPAN, FAX (0462) 29-8460 Kanagawa TEL (0462) 29-8468 Kanagawa TEL (0462) 47-211 Tokyo TEL (0462) 47-1729 Tokyo TEL (036) 3346-7550 FAX (0462) 47-1729 Tokyo TEL		
Raleigh (919) 878-8111 OHIO, (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7630 Dallas (214) 934-9039 Houston (713) 376-8084 International (713) 376-8084 BELGIUM, Antwerpen TEL (03) 248 46 42 FRANCE, Paris FAX (03) 248 46 42 FRANCE, Paris TEL (1) 49-75-10-10 GERMANY, Bad Homburg TEL (06172)-24061 München TEL (089) 45053-0 (06172)-23195 München TEL (089) 45053-0 (089) 406490 HONG KONG, FAX (089) 390541 (082) 865-4335 ITALY, Milano TEL (02) 3390541 (02) 3390541 JAPAN, FAX (0462) 29-8468 Kanagawa FAX (0462) 47-2911 Tokyo TEL (0462) 47-1729 Tokyo FAX (0462) 47-1729 Tokyo TEL (03) 3342-5196 (0	NORTH CAROLINA	
OHIO, Columbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International	Charlotte	
Columbus (Westerville) (614) 891-6455 Dayton (513) 439-0268 OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International	Haleigh	
Dayton (513) 439-0268 OREGON (503) 245-0800 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7630 Dallas (214) 934-9099 Houston (713) 376-8084 International (713) 376-8084 BELGIUM, Antwerpen TEL Muston (713) 248 43 00 FRANCE, Paris TEL FAX (03) 248 46 42 FRANCE, Paris TEL GERMANY, FAX Bad Homburg TEL (06172)-24061 FAX (06172)-24061 München TEL (089) 406490 HONG KONG, FAX TEL (089) 406490 HONG KONG, TEL (852) 865-4325 Wanchai FAX (02) 38103458 JAPAN, FAX Atsugi TEL (0462) 47-1712 Tokyo TEL (0462) 47-1712 Tokyo <td>Onio,</td> <td>II-></td>	Onio,	II->
OREGON (503) 245-0080 PENNSYLVANIA (215) 398-8006 TEXAS, (215) 398-8006 Austin (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International	Columbus (westervil	lie)(614) 891-6455
TEXAS, (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International (713) 376-8084 BELGIUM, Antwerpen TEL (03) 248 43 00 FAX FRANCE, Paris TEL TEL (1) 49-75-10-10 GERMANY, FAX Bad Homburg TEL (06172)-23195 München TEL (089) 445053-0 HONG KONG, TEL (082) 865-4335 Vanchai FAX (02) 38103458 JAPAN, FAX (0462) 29-8460 Atsugi TEL (0462) 29-8468 Kanagawa FAX FAX (0462) 29-8469 FAX (0462) 29-8469 Atsugi TEL (0462) 29-8469 FAX (0462) 29-8458 Kanagawa FAX (0462) 29-8469 FAX (0462) 47-2911 Tokyo TEL (0462) 47-1729 Tokyo FAX (0462) 47-1729 Tokyo <td>Dayton</td> <td>(513) 439-0268</td>	Dayton	(513) 439-0268
TEXAS, (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International (713) 376-8084 BELGIUM, Antwerpen TEL (03) 248 43 00 FAX FRANCE, Paris TEL TEL (1) 49-75-10-10 GERMANY, FAX Bad Homburg TEL (06172)-23195 München TEL (089) 445053-0 HONG KONG, TEL (082) 865-4335 Vanchai FAX (02) 38103458 JAPAN, FAX (0462) 29-8460 Atsugi TEL (0462) 29-8468 Kanagawa FAX FAX (0462) 29-8469 FAX (0462) 29-8469 Atsugi TEL (0462) 29-8469 FAX (0462) 29-8458 Kanagawa FAX (0462) 29-8469 FAX (0462) 47-2911 Tokyo TEL (0462) 47-1729 Tokyo FAX (0462) 47-1729 Tokyo <td>OREGON</td> <td>(503) 245-0080</td>	OREGON	(503) 245-0080
Austin (512) 346-7830 Dallas (214) 934-9099 Houston (713) 376-8084 International (713) 376-8084 BELGIUM, Antwerpen TEL	PENNSYLVANIA	
International (713) 376-8084 International (03) 248 43 00 BELGIUM, Antwerpen TEL (03) 248 43 00 FRANCE, Paris TEL (1) 49-75-10-10 GERMANY, FAX (1) 49-75-10-10 GERMANY, Bad Homburg TEL (06172)-24061 München TEL (06172)-24061 München TEL (089) 406490 HONG KONG, TEL (089) 406490 HONG KONG, TEL (02) 3390541 TALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 38103458 Kanagawa TEL (0462) 29-8460 FAX (0462) 29-8460 FAX YaPAN, FAX (0462) 47-2911 Tokyo TEL (0462) 47-211 Tokyo TEL (0462) 47-1729 Tokyo TEL (03) 3342-5196 Gaaka TEL (03) 3342-5196	IEXAS,	
International (713) 376-8084 International (03) 248 43 00 BELGIUM, Antwerpen TEL (03) 248 43 00 FRANCE, Paris TEL (1) 49-75-10-10 GERMANY, FAX (1) 49-75-10-13 GERMANY, Bad Homburg TEL (06172)-24061 München TEL (06172)-24061 München TEL (089) 406490 HONG KONG, TEL (089) 406490 HONG KONG, TEL (02) 3390541 TALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 3390541 JAPAN, FAX (0462) 29-8460 Kanagawa TEL (0462) 29-8460 FAX (0462) 29-8458 Kanagawa FAX (0462) 47-2911 FAX Tokyo TEL (0462) 47-2914 FAX (0462) 47-1729 Tokyo FAX (0462) 47-1729 Tokyo FAX (0462) 47-214 FAX FAX (0462) 47-219 Tokyo FAX (0462) 47-1729 Tokyo FAX	Austin	
International (713) 376-8084 International (03) 248 43 00 BELGIUM, Antwerpen TEL (03) 248 43 00 FRANCE, Paris TEL (1) 49-75-10-10 GERMANY, FAX (1) 49-75-10-13 GERMANY, Bad Homburg TEL (06172)-24061 München TEL (06172)-24061 München TEL (089) 406490 HONG KONG, TEL (089) 406490 HONG KONG, TEL (02) 3390541 TALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 3390541 JAPAN, FAX (0462) 29-8460 Kanagawa TEL (0462) 29-8460 FAX (0462) 29-8458 Kanagawa FAX (0462) 47-2911 FAX Tokyo TEL (0462) 47-2914 FAX (0462) 47-1729 Tokyo FAX (0462) 47-1729 Tokyo FAX (0462) 47-214 FAX FAX (0462) 47-219 Tokyo FAX (0462) 47-1729 Tokyo FAX	Dallas	
BELGIUM, Antwerpen TEL (03) 248 43 00 FRANCE, Paris FAX (03) 248 46 42 FRANCE, Paris TEL (1) 49-75-10-10 GERMANY, FAX (1) 49-75-10-13 Bad Homburg TEL (06172)-24061 FAX (06172)-24061 FAX München TEL (0652)-24061 München TEL (06172)-24061 München TEL (06172)-24061 Wanchai FAX (06172)-24061 Wanchai TEL (089) 45053-0 ITALY, Milano TEL (089) 406490 HONG KONG, TEL (082) 865-4335 ITALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 38103458 Kanagawa TEL (0462) 29-8468 Kanagawa TEL (0462) 47-2911 FAX (0462) 47-2911 FAX Tokyo TEL (0462) 47-1729 Tokyo TEL (03) 3342-5196 Osaka TEL (06) 243-3250	Houston	
FAX (03) 248 46 42 FRANCE, Paris TEL (1) 49-75-10-10 GERMANY, FAX (1) 49-75-10-13 Bad Homburg TEL (06172)-24061 FAX (06172)-23195 München TEL (089) 406490 HONG KONG, TEL (852) 865-4325 ITALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 38103458 Kanagawa TEL (0462) 29-8460 FAX (0462) 47-2911 Tokyo TEL (0462) 47-2917 Tokyo TEL (0462) 47-2917 Tokyo TEL (0462) 47-2914 FAX (0462) 47-2914 17-1729 Tokyo TEL (03) 3346-7550 FAX (0462) 47-2914 17-1729 Tokyo TEL (03) 3342-5196 Osaka TEL (06) 243-3250		
FHANCE, Paris TEL (1) 49-75-10-10 GERMANY, FAX (1) 49-75-10-13 Bad Homburg TEL (06172)-24061 FAX (06172)-23195 München München TEL (089) 45053-0 HONG KONG, TAX (089) 406490 HONG KONG, TEL (082) 865-4325 TALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 38103458 Kanagawa TEL (0462) 29-8460 FAX (0462) 29-8468 Kanagawa FAX (0462) 47-2911 Tokyo TeL (03) 3346-7550 FAX Gaska TEL (03) 3342-5196	BELGIUM, Antwerpen	TEL
FHANCE, Paris IEL (1) 49-75-10-10 GERMANY, FAX (1) 49-75-10-13 Bad Homburg TEL (06172)-24061 FAX (06172)-23195 München München TEL (089) 45053-0 HONG KONG, TEL (089) 460490 HONG KONG, TEL (082) 865-4325 UTALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 38103458 Kanagawa TEL (0462) 29-8460 FAX (0462) 29-8468 Kanagawa FAX (0462) 47-2911 Tokyo Tel (03) 3346-7550 FAX FAX (0462) 47-1729 Tokyo FAX (0462) 47-3410 FAX Gosaka TEL (03) 3342-5196	FRANCE R .	FAX(03) 248 46 42
GERMANY, FAX (1) 49-75-10-13 Bad Homburg TEL (06172)-24061 FAX (06172)-23195 München TEL (089) 45053-0 HONG KONG, FAX (089) 406490 HONG KONG, TEL (852) 865-4335 TALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 3390541 Kanagawa TEL (0462) 29-8460 FAX (0462) 29-8460 FAX Yapan, TEL (0462) 47-2911 JAPAN, FAX (0462) 47-2914 Tel (0462) 29-8458 FAX Kanagawa TEL (0462) 47-2914 FAX (0462) 47-1729 Tokyo Tokyo TEL (03) 3342-5196 Gsaka TEL (06) 243-3250	FRANCE, Paris	I EL (1) 49-75-10-10
Bad Homburg TEL (06172)-24061 FAX (06172)-23195 München TEL (089) 45053-0 HONG KONG FAX (089) 406490 HONG KONG, TEL (852) 865-4335 TALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 38103458 Kanagawa TEL (0462) 29-8460 FAX (0462) 29-8460 FAX FAX (0462) 29-8458 Kanagawa FAX (0462) 47-2911 TeL Tokyo TEL (0462) 47-1729 Tokyo TEL (03) 3346-7550 FAX (062) 47-3250 FAX C03 aska TEL (03) 3342-5196		FAX (1) 49-75-10-13
Munchen IEL (089) 45053-0 FAX (089) 406490 HONG KONG, TEL (852) 865-4525 Wanchai FAX (852) 865-4525 Wanchai FAX (852) 865-4325 JAPAN, FAX (02) 38103458 JAPAN, FAX (0462) 29-8460 FAX (0462) 29-8458 Kanagawa TEL (0462) 47-2911 Tokyo TEL (0462) 47-1729 Tokyo TEL (03) 3342-5196 Osaka TEL (06) 243-3250	GERMANY,	
Munchen IEL (089) 45053-0 FAX (089) 406490 HONG KONG, TEL (852) 865-4525 Wanchai FAX (852) 865-4525 TALY, Milano TEL (02) 3390541 FAX (02) 38103458 JAPAN, FAX (0462) 29-8460 FAX (0462) 29-8458 Kanagawa TEL (0462) 47-2911 FAX (0462) 47-1729 Tokyo TEL (03) 3342-5196 Osaka TEL (06) 243-3250	Bad Homburg	TEL (06172)-24061
Munchen IEL (089) 45053-0 FAX (089) 406490 HONG KONG, TEL (852) 865-4525 Wanchai FAX (852) 865-4525 TALY, Milano TEL (02) 3390541 FAX (02) 38103458 JAPAN, FAX (0462) 29-8460 FAX (0462) 29-8458 Kanagawa TEL (0462) 47-2911 FAX (0462) 47-1729 Tokyo TEL (03) 3342-5196 Osaka TEL (06) 243-3250		FAX
FAX (089) 406490 HONG KONG, TEL (852) 865-4325 Wanchai FAX (852) 865-4325 TALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 38103458 Kanagawa TEL (0462) 29-8460 FAX (0462) 29-8458 Kanagawa TEL (0462) 47-2911 7-2911 Tokyo TEL (0462) 47-1729 Tokyo TEL (03) 3346-7550 FAX (03) 3342-5196 05 a48	München	IEL
Wanchai FAX (852) 865-4335 TALY, Milano TEL (02) 3390541 FAX (02) 38103458 JAPAN, (02) 88103458 Atsugi TEL (0462) 29-8460 FAX (0462) 29-8460 Kanagawa TEL (0462) 47-1729 Tokyo TEL (0462) 47-1729 Tokyo TEL		FAX (089) 406490
Wanchai FAX (852) 865-4335 TALY, Milano TEL (02) 3390541 FAX (02) 38103458 JAPAN, (02) 88103458 Atsugi TEL (0462) 29-8460 FAX (0462) 29-8460 Kanagawa TEL (0462) 47-1729 Tokyo TEL (0462) 47-1729 Tokyo TEL	HONG KONG,	TEL
TALY, Milano TEL (02) 3390541 JAPAN, FAX (02) 38103458 JAtsugi TEL (0462) 29-8460 FAX (0462) 29-8458 Kanagawa TEL (0462) 47-2911 Tokyo TEL (0462) 47-1729 Tokyo TEL (03) 3346-7550 FAX (03) 3342-5196 Osaka		
AFAN, TEL	TALY, Milano	TEL (02) 3390541
AFAN, TEL		FAX(02) 38103458
FAX (0462) 29-8458 Kanagawa TEL (0462) 47-2911 FAX (0462) 47-1729 Tokyo TEL (03) 3346-7550 FAX (03) 3342-5196 Osaka TEL (06) 243-3250		
FAX (0462) 29-8458 Kanagawa TEL (0462) 47-2911 FAX (0462) 47-1729 Tokyo TEL (03) 3346-7550 FAX (03) 3342-5196 Osaka TEL (06) 243-3250	Atsugi	TEL (0462) 29-8460
Kanagawa TEL		EAX (0460) 00 0460
FAX	Kanagawa	TEL
Tokyo		EAX (0462) 47 1720
FAX	Tokyo	TEI (03) 3346,7550
Osaka		FAX
FAX (06) 040 0050	Osaka	TEL
100 243-3253		FAX(06) 243-3253

International (Continued)

memanonai (
KOREA, Seoul	TEL	
	FAX	
LATIN AMERICA.		(0=) = 101 0011
	FAX	(305) 485-9736
SINGAPORE	TEL	(65) 3481188
	FAX	(65) 3480161
SWEDEN.		
Stockholm area	TEL	
(Bromma)	FAX	
TAIWAN, Taipei	TEL	(886) 2-7153536
	FAX	
UNITED KINGDOM,		
Manchester area	TEL	
(Warrington)	FAX	
London area	TEL	(0483) 740440
(Woking)	FAX	

North American Representatives _ CANADA ILLINOIS Skokie - INDUSTRIAL IOWA LORENZ SALES KANSAS Merriam – LORENZ SALES (913) 469-1312 MEXICO Chula Vista (CA) - SONIKA ELECTRONICA (619) 498-8340 MICHIGAN MISSOURI LORENZ SALES ... NEBRASKA NEW MEXICO THORSON DESERT STATES(505) 883-4343 NEW YORK East Syracuse - NYCOM, INC(315) 437-8343 Hauppauge – COMPONENT CONSULTANTS, INC(516) 273-5050 OHIO Centerville - DOLFUSS ROOT & CO(513) 433-6776 PENNSYLVANIA COMP REP ASSOC, INC UTAH FRONT RANGE MARKETING (801) 288-2500 WASHINGTON WISCONSIN Brookfield - INDUSTRIAL REPRESENTATIVES, INC(414) 574-9393

Co)

11/29/93 Printed in USA

Advanced Micro Devices reserves the right to make changes in its product without notice in order to improve design or performance characteristics. The performance Advances inside periods reserves into fight to make changes in a product window notice in comprove cessing or performance characteristics into period background and the practice sources to the industry. For specific testing details, contact your local AMD sales representative. The company assumes no responsibility for the use of any circuits described herein. RECYCLED & RECYCLABLE

Advanced Micro Devices, Inc. 901 Thompson Place, P.O. Box 3453, Sunnyvale, CA 94088, USA Tel: (408) 732-2400 • TWX: 910-339-9280 • TELEX: 34-6306 • TOLL FREE: (800) 538-8450 APPLICATIONS HOTLINE & LITERATURE ORDERING • TOLL FREE: (800) 222-9323 • (408) 749-5703 © 1994 Advanced Micro Devices, Inc. 17815B Con-6M-2/94-0