




Use the attached rack mounting template to locate the holes on the front and rear rack mounting flanges.



Install cage nuts or clip nuts as required for your rack cabinet. Use the cage-nut-insertion tool or a flat-blade screwdriver to install cage nuts.




Use the tab **1** on the rear of each slide rail to align the slide rail to the rear mounting flanges. If the front slide rail bracket does not align with the front mounting flange, slightly loosen the rail-length-adjusting screws **2** and adjust the length of the rail.




Install the slide rails, ensuring that the front and rear slide rail brackets for both slide rails are vertically aligned. Insert and partially tighten the four rear M6 screws **1**; then, insert and fully tighten the four front M6 screws **2**.

If you loosened the rail-length-adjusting screws, tighten them; then, fully extend the rails out of the rack cabinet until they lock into place.




**Attention:** To avoid injury, do not place your fingers around the rack-support wheels **1** when positioning the server on the rails.

Ensure that the handles **2** are fully upright as shown in the illustration above; then, use the handles to position the server in front of and level with the rails, aligning the channels on the sides of the server with the rails. Slide the server onto the rails, resting the rack-support wheels on the rails, until the release latches contact the rails.




Use four M4 screws per side to secure the server to the rails; then, remove the rack-support wheels **1** and the handles **2** and store them in a safe place. Also remove the blue thumbscrew **3** from the left side of the server and store it in a safe place.


**Note:** The rack-support wheels and the handles are required if you remove the server from the rack cabinet. You must also install the blue thumbscrew if you intend to remove the server from the rack cabinet and move the server to a new location.




Insert the tab on the bottom edge of the cable management arm hinge plate **1** into the slot at the rear-left side of the server; then, attach the plate to the server with the M3.5 thumbscrew.




Press in on the slide-rail-locking latches and slide the server fully into the rack cabinet. Slide the cable-management-arm bracket over the right-rear M6 screws **1**. Ensure that both rear slide-rail brackets are vertically aligned; then, fully tighten the four rear M6 screws.




Slide the server halfway out of the rack cabinet; then, loosen but do not remove the four front M6 screws **1**. While one person supports the front of the server by lifting it slightly, ensure that the front slide-rail brackets are vertically aligned; then, fully tighten the four front M6 screws.




Slide the server fully into the rack cabinet until it locks in place. Using the handles **1** on the free end of the cable management arm, retract the spring-loaded hinge pins **2**; then, rotate the handles to lock the pins in the retracted position.



Slide the tab **1** on the cable management arm into the slot **2** in the hinge plate; then, release the hinge pins into the holes in the plate.




Attach cables to the rear of the server (such as keyboard, mouse, and monitor cables if required). Route the cables toward the left side of the server. Use cable clamps to secure cables along the way. Insert clamps only in the column of ventilation holes immediately to the right of the ac power connectors. If you insert the clamps in columns elsewhere, they will interfere with the removal of internal components.




Route the cables through the cable-management arm, securing them with cable straps **1**. Use two cable straps **2** (one on each side of the hinge) to secure the power cords to the hinge plate.

See the documentation that comes with your server and optional devices for complete cabling instructions.



Slide the server into the rack cabinet until the release latches **1** lock into place.

**Note:** If you move the rack cabinet or install it in a vibration-prone area, insert the M6 screws **2**; then, install the chassis support bracket (see Step 15). If the server comes installed in the rack cabinet, the bracket also comes installed and need not be removed.



**Important:** The chassis support bracket must be installed if you move the rack cabinet after you install the server.

Align the bracket **2** so that the tab **3** engages the lower rear of the server. Install cage nuts or clip nuts, depending on your rack cabinet, on the rear mounting flanges in holes that align with the holes in the bracket; then, insert and fully tighten four M6 screws **1**.

Store this information with your server documentation for future use.

---

**Third Edition (November 2002)**

IBM, NetBAY, and Netfinity are trademarks of the IBM Corporation in the United States, other countries, or both.

© Copyright 2002 International Business Machines Corporation. All rights reserved.

Note to U.S. Government Users — Documentation related to restricted rights — Use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

**Part Number: 02R2725**

**Printed in U.S.A.**



\*1P02R2725\*